



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	2099	CARBURETOR ASSEMBLY, COM	2,2		
2	1399	110A 1	FLOAT ASSEMBLY	2,2		
3	17	20853	PIN, FLOAT LEVER PINION	4,4		
4	1399	102	LEVER, FLOAT (LOWER)	2,2		
5	1399	101	LEVER, FLOAT (UPPER)	2,2		
6	1399	1473	INLET NEEDLE, SEAT AND GA	2,2		
7	27	25033	GASKET, INLET SEAT	2,2		
8	1399	99	GASKET, FLOAT BOWL COVER	2,2		
9	1399	1133	COVER, FLOAT BOWL	2,2		
10	10	20854	SCREW, FLOAD BOWL COVER	2,2		
11	10	25850	SCREW, FLOAD BOWL COVER	2,2		
12	27	25851	GASKET, STRAINER COVER (L	2,2		
13	1399	1754	SCREEN, FILTER	2,2		
14	27	25849	GASKET, STRAINER COVER SC	2,2		
15	1399	1135	COVER, STRAINER	2,2		
15	27	25848	GASKET, STRAINER COVER SC	2,2		
16	27	25848	GASKET, STRAINER COVER SC	2,2		
17	10	25822	SCREW, STRAINER COVER FA	2,2		
18	10	20847	SCREW, THORTTLE STOP LEV	2,2		
19	1399	97	LEVER, THORTTLE STOP (SEE N	2,2		
20	1399	2012	SAHFT, THORTTLE	2,2		
21	1399	1710	TUBE, IDLE	2,2		
22	27	23180	GAKET, IDLE TUBE	2,2		
23	10	23035	SCREW AND LOCKWASHER, T	4,4		
24	1399	1711	SHUTTER, THROTTLE	2,2		
25	24	27160	SPRING, IDLE ADJUSTMENT S	2,2		
26	1399	1713	SCREW, IDLE ADJUSTMENT	2,2		
27	10	28405	SCREW, PLUG - MAIN FUEL JE	2,2		
28	27	28406	GASKET, JET CHANNEL PLUG	2,2		
29	1399	1461	JET, MAIN FUEL (.061)	OPT,OI		
29	1399	1459	JET, MAIN FUEL (.059) - STAND	2,2		
29	1399	1457	JET, MAIN FUEL (.057)	OPT,OI		
29	1399	1655	JET, MAIN FUEL (.055)	OPT,OI		
30	27	28409	GASKET, MAIN FUEL JET	2,2		
31	1399	1888	NOZZLE, MAIN	2,2		
32	10	23178	SCREW, PLUG - MAIN NOZZLE	2,2		
33	24	26890	SPRING, THROTTLE SHAFT RE	1,1		
33	24	20869	SPRING, THROTTLE SHAFT RE	1,1		
34	10	23030	SCREW, PLUG - BODY CHANNI	2,2		
35	19	20011	WELCH PLUG, BODY CHANNEL	2,2		
	1399	1477	GASKET AND PACKING SET (1 P	2,2		