



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1626	2040A 3	GEAR HOUSING ASSY.COMP.(ST	1,1,1,1		
1	1626	2040A 1	GEAR HOUSING ASSEMBLY(SEE	1,1,1,1		
43		30147	CAM,SHIFT	1,1,1,1		
44		20930	FOLLOWER,CAM	1,1,1,1		
45		20843	SLIDEE,CROSS PIN	1,1,1,1		
46	24	20254	SPRING,COMPRESSION - CAM FI	1,1,1,1		
47	15	31154A 1	SHIM,BEARING CUP TO GEAR HI	AR,AR,		
48	43	20975	FORWARD GEAR ASSEMBLY	1,1,1,1		
49	31	20249	BEARING,ROLLER - FORWARD	1,1,1,1		
50	31	31215A 1	TAPARED ROLLER BEARING A	1,1,1,1		
51	31	31216	CUP,TAPERED ROLLER BEAF	1,1,1,1		
52	52	32189	RATCHET,SLIDING CLUTCH	1,1,1,1		
53	17	20841	PIN,CROSS - RATCHET TO PROF	1,1,1,1		
54	53	20842	RING,RETAINING - CROSS PIN	1,1,1,1		
55	44	32000	SHAFT,PROPELLER	1,1,1,1		
56	43	20975	REEVERSE GEAR ASSEMBLY	1,1,1,1		
57	12	32004	WASHER,THRUST - REVERSE	1,1,1,1		
58	30	20839	BEARING,BALL - REVERSE GE	1,1,1,1		
59	15	20927A 1	SHIM,THRUSTT WASHER TO GE	AR,AR,		
60	25	31986	"O"RING,BEARING CARRIER	1,1,1,1		
61		32015A 1	BEARING CARRIER ASSEMBLY	1,1,1,1		
62	31	20249	BEARING,ROLLER - BEARING C	1,1,1,1		
63	26	23300	OIL SEAL,BEARING CARRIER	1,1,1,1		
64	28	30281	KEY,LOCATING - BEARING CARR	1,1,1,1		
65	12	31993	WASHER,GEAR HOUSING COVE	1,1,1,1		
66		32014	COVER,GEAR HOUSING	1,1,1,1		
67	12	25251	WASHER,BACKING - PROPELLEF	1,1,1,1		
68		32002A 1	THRUSTT HUB AND WAHSER A	1,1,1,1		
69	12	31992	WASHER,CUPPED - THRUST HU	1,1,1,1		
70	12	32007	WASHER,SPLINED - PROPELLEF	1,1,1,1		
71	11	31990	NUT,PROPELLER	1,1,1,1		
72		31640	TRIM TAB,GEAR HOUSING	1,1,1,1		
73	10	32470	SCREW,TRIM TAB TO GEAR HO	1,1,1,1		
74	11	22178	NUT,DRIVE SHAFT HOUSING TO	1,1,1,1		
75	11	23161	NUT,DRIVE SHAFT HOUSING TO	1,1,1,1		