



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1603	1868A 2	GEAR HOUSING ASSEMBLY, CO	1,1	SEE NOTE BELOW	
1	1603	1868A 1	GEAR HOUSING ASSEMBLY	1,1	SEE PAGE 34 FOR PARTS BREA	
34	32	23652	TUBE, WATER INLET - LOWER	1,1		
35	23	23651	SLEEVE, WATER INLET TUBE	1,1		
36	26	20232	SEAL, WATER TUBE	3,3		
37	35	23654	SCREEN, WATER INTAKE - GE	1,1		
--	27	31367	GASKET, WATER INTAKE SCR	1,1	SERIAL 01448240-01460498	
38		30147	CAM, SHIFT	1,1		
39		20930	FOLLOWER, CAM	1,1		
40		20843	SLIDE, CROSS PIN	1,1		
41	24	20254	SPRING, CAM FOLLOWER PIN	1,1		
42	15	31154A 1	SHIM, TAPERED BEARING CUF	AR,AR		
--	43	20975A 3	FORWARD GEAR ASSEMBLY, C	1,1		
43	31	31215A 1	TAPERED ROLLER BEARING	1,1		
44	31	31216	CUP, TAPERED ROLLER BE	1,1		
45	43	20975	FORWARD GEAR ASSEMBLY	1,1		
46	31	20249	BEARING, ROLLER - FORWA	1,1		
47	52	32189	RATCHET, SLIDING CLUTCH	1,1		
48	17	20841	PIN, CROSS - RATCHET TO PR	1,1		
49	53	20842	RING, RETAINING - CROSS PIN	1,1		
50	44	25254	SHAFT, PROPELLER	1,1		
--	43	20975A 2	REVERSE GEAR ASSEMBLY, C	1,1		
51	43	20975	REVERSE GEAR ASSEMBLY	1,1		
52		20864	RING, ADAPTOR - BALL BEAF	1,1		
53	30	20839	BEARING, BALL - REVERSE C	1,1		
54	15	20927A 1	SHIM, ADAPTOR RING TO GEA	AR,AR		
55	25	20863	"O"RING, BEARING CARRIER	1,1		
56		20862A 1	BEARING CARRIER ASSEMBLY	1,1		
57	31	20249	BEARING, ROLLER	1,1		
58	26	23300	OIL SEAL	1,1		
59	12	22970	WASHER, GEAR HOUSING COV	1,1		
60		20865	COVER, GEAR HOUSING	1,1		
61	12	25251	WASHER, BACKING (1/8)	AR,AR		
62	48	22914A 2	PROPELLER ASSEMBLY, COMPL	1,1		
63	12	25252	WASHER, BACKING (1/32)	1,1		
64	14	25250	TAB WASHER, PROPELLER NL	1,1		
65	11	20837	NUT, PROPELLER (ALUMINUM)	1,1		
65	11	29825	NUT, PROPELLER (NYLON)	OPT..0		