

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	177	1594A 6	TOP COWL ASSEMBLY	1,....		
1	177	1594A 2	TOP COWL ASSEMBLY	.1,1,1,1		
2	16	20500	STUD, REAR - TOP COWL TO C	2,2,2,2		
3	16	20353	STUD, FRONT - TOP COWL TO	2,2,2,2		
4	25	20116	GROMMET, CHOKE KNOB	1,1,1,1		
5		28967	SCREEN, VENT - TOP COWL	1,1,1,1		
6	10	29221	SCREW, VENT SCREEN TO TO	4,4,4,4		
7		29228A 1	TRIM MOULDING ASSEMBLY, 1	1,1,1,1		
8	10	29226	SCREW, DECORATIVE - MOU	2,2,2,2		
9	10	29227	SCREW, BRASS - MOULDING	2,2,2,2		
10	13	26395	LOCKWASHER, MOULDING F	4,4,4,4		
11	11	26419	NUT, MOULDING FASTENING	4,4,4,4		
--	37	31156A 1	DECAL SET, TOP COWL	.1,1,...		
12	23	20326	SPACER, TOP COWL STUD	2,2,2,2		
13	12	20028	WASHER, TOP COWL STUD (1/1	2,2,2,2		
14	12	20346	WASHER, TOP COWL STUD (3/4	4,4,4,4		
14	12	20346	WASHER, TOP COWL STUD (3/4	....6,6		
15	12	20583	WASHER, TOP COWL STUD (1/3	4,4,4,4		
16	11	20361	NUT, TOP COWL FASTENING	4,4,4,4		
17		20155	RETAINER, STARTER SPRING	1,1,1,1		
18	24	29340A 1	SPRING, STARTER REWIND	1,1,1,1		
19	23	28912	BUSHING, SPRING GUIDE	1,1,1,1		
20	50	28908	SHEAVE ASSEMBLY	.1,1,...		
21		20162	PAWL, STARTER	.3,3,...		
22	13	29402	WASHER, WAVE - STARTER PA	.3,3,...		
20	50	30994	SHEAVE ASSEMBLY	1,1,1,1	SEE NOTE BELOW	
21		30596	PAWL, STARTER	3,3,3,3	SEE NOTE BELOW	
22	13	30597	WASHER, WAVE - STARTER PA	3,3,3,3	SEE NOTE BELOW	
23	23	28919	BUSHING, NYLON - SHEAVE SHA	1,1,1,1		
24	23	28911	SPACER, SHEAVE SHAFT	1,1,1,1		
25		26179	RETAINER, WAVE WASHER	1,1,1,1		
26	12	26180	WASHER, WAVE WASHER RETA	1,1,1,1		
27	13	20160	WASHER, WAVE - RETAINER TE	1,1,1,1		
28		20164	PLATE, RETAINER - STARTER P	.1,1,...		
28		30595	PLATE, RETAINER - STARTER P	1,1,1,1	SEE NOTE BELOW	
29		28913	SHAFT, SHEAVE	1,1,1,1		
30	50	28985A 1	STARTER CABLE ASSEMBLY	1,1,1,1		
31		28747	HANDLE, STARTER CABLE	1,1,1,1		
32		28748	RETAINER, STARTER CABLE AN	1,1,1,1		
33		30045	PLATE, ROPE GUIDE	1,1,1,1		
34	10	28642	SCREW, DRIVE ROPE GUIDE PL	2,2,2,2		

