



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	103	2354A 2	BOTTOM COWL ASSEMBLY	1,1		
2		29206	COVER, PLUG - BOTTOM COWL	1,		
2		29206	COVER, PLUG - BOTTOM COWL	*		
3	10	26128	SCREW, PLUG COVER TO BOT	4,		
3	10	45893	SCREW, PLUG COVER TO BOT	*		
4	13	26395	LOCKWASHER, PLUG COVER F	4,		
4	13	26395	LOCKWASHER, PLUG COVER F	*		
5	11	26419	NUT, PLUG COVER FASTENING	4,		
5	11	26419	NUT, PLUG COVER FASTENING	*		
6		26552	SUPPORT, EXTERNAL WIRING F	,1		
7	10	20639	SCREW, HARNESS SUPPORT TO	,1		
8	12	20084	WASHER, HARNESS SUPPORT F	,1		
9	11	29250	NUT, HARNESS SUPPORT FAST	,1		
10		23760	BAFFLE, BOTTOM COWL	1,1		
11	10	21106	SCREW, BAFLE TO BOTTOM COW	3,3		
12		30999	BRACKET, LOCK KNOB - COWL F	1,1		
13	10	21091	SCREW, BRACKET TO BOTTOM	3,3		
14	11	20184	NUT, BRACKET FASTENING SCR	3,3		
15		21104A 2	CONNECTOR BASE ASSEMBLY	1,1		
16	13	21972	LOCKWASHER, CONNECTOR E	1,1		
17	11	21971	NUT, CONNECTOR BASE TO BI	1,1		
18	54	25231	CLIP, CONNECTOR BASE LEAD V	1,1		
19	10	22815	SCREW, LEAD WIRE CLIP TO BO	1,1		
20	32	29164	TUBE, VENT - MAGNETO OUTLE	2,2		
21	22	25885	ELBOW, MAGNETO VENT TUBE	2,2		
22	19	32297	PLUG, BOTTOM COWL HOLE	1,1		
23		20557	BRACKET, CABLE END ANCHOR	4,4		
24	10	29200	SCREW, ANCHOR BRACKET TO	4,4		
25		29532	LEVER, THROTTLE CONTROL	1,1		
26		29824	LEVER, SHIFT CONTROL	1,1		
27	23	29529	BUSHING, THROTTLE AND SHIF	2,2		
28	12	29395	WASHER, THROTTLE AND SHIF	4,4		
29	10	26632	SCREW, THROTTLE AND SHIF	2,2		
30	17	30978A 1	PIN ASSEMBLY, CLEVIS YOKE	2,2		
31	17	23928	ROLL PIN, CLEVIS YOKE PIN	2,2		
32	10	20584	SCREW, CLEVIS YOKE PIN TO CI	2,2		
33	13	29402	WASHER, WAVE - CLEVIS PIN FA	2,2		
34	11	29488	NUT, CLEVIS PIN FASTENING SC	2,2		
35		25180	SHIFT SHAFT ASSEMBLY, UPPE	1,1		
36		27714	ROD (SLEEVE), SHIFT CONTROL	1,1		
37	11	26168	NUT, ADJUSTING, SHIFT SHAFT	1,1		