



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	2099	CARBURETOR ASSEMBLY, COM	2,2		
2	1399	110A 1	FLOAT ASSEMBLY	2,2		
3	17	20853	PIN, FLOAT LEVER PINION	4,4		
4	1399	102	LEVER, FLOAT (LOWER)	2,2		
5	1399	101	LEVER, FLOAT (UPPER)	2,2		
6	1399	1473	INLET NEEDLE, SEAT AND GASK	2,2		
7	27	25033	GASKET, INLET SEAT	2,2		
8	1399	99	GASKET, FLOAT BOWL COVER	2,2		
9	1399	1133	COVER, FLOAT BOWL	2,2		
10	10	20854	SCREW, FLOAT BOWL COVER (S	2,2		
11	10	25850	SCREW, FLOAT BOWL COVER (L	2,2		
12	27	25851	GASKET, STRAINER COVER (LAF	2,2		
13	1399	1754	SCREEN, FILTER	2,2		
14	27	25849	GASKET, STRAINER COVER (SM	2,2		
15	1399	1135	COVER, STRAINER	2,2		
16	27	25848	GASKET, STRAINER COVER SCF	2,2		
17	10	25822	SCREW, STRAINER COVER FAS	2,2		
18	10	20847	SCREW, THROTTLE STOP LEVE	2,2		
19	1399	97	LEVER, THROTTLE STOP (SEE N	2,2		
20	1399	1475	SHAFT, THROTTLE	2,2		
21	1399	1710	TUBE, IDLE	2,2		
22	27	23180	GASKET, IDLE TUBE	2,2		
23	10	23035	SCREW AND LOCKWASHER, TH	4,4		
24	1399	1711	SHUTTER, THROTTLE	2,2		
25	24	27160	SPRING, IDLE ADJUSTMENT SCI	2,2		
26	1399	1713	SCREW, IDLE ADJUSTMENT	2,2		
27	10	28405	SCREW, PLUG - MAIN FUEL JET	2,2		
28	27	28406	GASKET, JET CHANNEL PLUG SI	2,2		
29	1399	1461	JET, MAIN FUEL (.061)	OPT,01		
29	1399	1459	JET, MAIN FUEL (.059) - STANDAI	2,2		
29	1399	1457	JET, MAIN FUEL (.057)	OPT,.0		
29	1399	1655	JET, MAIN FUEL (.055)	OPT,.0		
30	27	28409	GASKET, MAIN FUEL JET	2,2		
31	1399	1888	NOZZLE, MAIN	2,2		
32	10	23178	SCREW, PLUG - MAIN NOZZLE	2,2		
33	24	26890	SPRING, THROTTLE SHAFT RET	1,1		
33	24	20869	SPRING, THROTTLE SHAFT RET	1,1		
34	10	23030	SCREW, PLUG - BODY CHANNEL	2,2		
35	19	20011	WELCH PLUG, BODY CHANNEL	2,2		
--	1399	1477	GASKET AND PACKING SET (1 PI	2,2		
--	1399	1877	REPAIR PARTS KIT (1 PER CARB	2,2		