



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1626	2470A 3	GEAR HOUSING ASSEMBLY, CO	1,1,,		
-		2470A 4	GEAR HOUSING ASSEMBLY, CO	1,1,,		
-	1626	2470A18	GEAR HOUSING ASSEMBLY, CO	,,1,1		
-	1626	2470A19	GEAR HOUSING ASSEMBLY, CO	,,1,1		
1	1626	2470A 1	GEAR HOUSING ASSEMBLY	1,1,,		
1	1626	2470A16	GEAR HOUSING ASSEMBLY	,,1,1		
2	31	20231	BEARING, ROLLER - DRIVE S	1,1,1,1		
3	16	37728	STUD, WATER PUMP BODY	3,3,3,3		
4	16	32017	STUD, GEAR HOUSING TO D	2,2,,		
4	16	45177	STUD, GEAR HOUSING TO D	,,2,2		
5	12	45176	WASHER, GEAR HOUSING STL	2,2,2,2		
6		38071	PLATE, SUPPORT - EXHAUST	1,1,1,1		
7		37721	SEAL, EXHAUST TUBE	1,1,1,1		
8	43	20834	GEAR, PINION - DRIVE SHAFT	1,1,1,1		
9	14	29163	TAB WASHER, PINION GEAR S	1,1,1,1		
10	10	20925	SCREW, PINION GEAR TO DRIP	1,1,1,1		
11		32008	SHAFT, SHIFT - LOWER	1,1,1,1		
12	18	20233	CLIP, RETAINING - SHIFT SHAF	1,1,1,1		
13	25	25439	"O" RING, SHIFT SHAFT BUSHI	1,1,1,1		
14	23	28374A 1	BUSHING ASSEMBLY, SHIFT SI	1,1,,		
14	23	38993A 2	BUSHING ASSEMBLY, SHIFT SI	,,1,1		
15	26	31249	OIL SEAL, SHIFT SHAFT BUSI	1,1,1,1		
16	12	31266	WASHER, RUBBER - SHIFT S	,,1,1		
17		25138	CAM, LOWER - REVERSE LOCK	1,1,1,1		
18		29823	CAM, UPPER - REVERSE LOCK	1,1,1,1		
19	45	38466	DRIVE SHAFT (SHORT SHAFT)	1,1,1,1		
19	45	38467	DRIVE SHAFT (LONG SHAFT)	1,1,1,1		
20	15	20929A 1	SHIM, BEARING TO GEAR HOU	AR,AR,		
21	30	20861	BEARING, BALL - DRIVE SHAFT	1,1,1,1		
22	53	29116	RING, SNAP - BALL BEARING R	1,1,1,1		
23	15	20929A 1	SHIM, BEARING TO WATER PL	AR,AR,		
24	27	32771	GASKET, WATER PUMP BASE	1,1,1,1		
25	25	26855	"O" RING, WATER PUMP BASE	1,1,1,1		
26	46	32766A 1	WATER PUMP BASE ASSEMBL	1,1,,		
26	46	39531A 1	WATER PUMP BASE ASSEMBL	,,1,1		
27	26	26782	OIL SEAL, WATER PUMP BAS	,,1,1		
28	26	23300	OIL SEAL, WATER PUMP BAS	1,1,1,1		
29	17	35973	DOWEL PIN, WATER PUMP E	2,2,2,2		
30	27	32769	GASKET, LOWER - WATER PUI	1,1,1,1		
31		32768	PLATE, FACE - WATER PUMP E	1,1,1,1		
32	27	32770	GASKET, UPPER - FACE PLAC	1,1,1,1		