



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	2539	CARBURETOR ASSEMBLY, COM	2,2,2,2		#
1	1333	2741	CARBURETOR ASSEMBLY, COM	,2,2		*
2	1399	110A 1	FLOAT ASSEMBLY	2,2,2,2		
3	17	20853	PIN, FLOAT LEVER PINION	4,4,4,4		
4	1399	102	LEVER, FLOAT (LOWER)	2,2,2,2		
5	1399	101	LEVER, FLOAT (UPPER)	2,2,2,2		
6	1399	1473	INLET NEEDLE, SEAT AND GA	2,2,2,2		
7	27	25033	GASKET, INLET SEAT	2,2,2,2		
8	1399	99	GASKET, FLOAT BOWL COVER	2,2,2,2		
9	1399	1133	COVER, FLOAT BOWL	2,2,2,2		
10	10	20854	SCREW, FLOAT BOWL COVER	2,2,2,2		
11	10	25850	SCREW, FLOAT BOWL COVER	2,2,2,2		
12	27	25851	GASKET, STRAINER COVER (L	2,2,2,2		
13	1399	1754	SCREEN, FILTER	2,2,2,2		
14	27	25849	GASKET, STRAINER COVER (S	2,2,2,2		
15	1399	1135	COVER, STRAINER	2,2,2,2		
16	27	25848	GASKET, STRAINER COVER SC	2,2,2,2		
17	10	25822	SCREW, STRAINER COVER FA	2,2,2,2		
18	10	20847	SCREW, THROTTLE STOP LEV	2,2,2,2		
19	1399	97	LEVER, THROTTLE STOP (SEE	2,2,2,2		
20	1399	2012	SHAFT, THROTTLE	2,2,2,2		
21	1399	2560	TUBE, IDLE	2,2,2,2		
22	27	23180	GASKET, IDLE TUBE	2,2,2,2		
23	10	23035	SCREW AND LOCKWASHER, T	4,4,4,4		#
23	10	20858	SCREW AND LOCKWASHER, T	,4,4		*
24	1399	1476	SHUTTER, THROTTLE	2,2,2,2		
25	24	27160	SPRING, IDLE ADJUSTMENT S	2,2,2,2		
26	1399	1713	SCREW, IDLE ADJUSTMENT	2,2,2,2		
27	10	28405	SCREW, PLUG - MAIN FUEL JE	2,2,2,2		
28	27	28406	GASKET, JET CHANNEL PLUG	2,2,2,2		
29	1399	1463	JET, MAIN FUEL (.063)	,2,2		*
29	1399	1461	JET, MAIN FUEL (.061)	OPT,OI		
29	1399	1459	JET, MAIN FUEL (.059)	OPT,OI		
29	1399	1457	JET, MAIN FUEL (.057)	2,2,2,2		#
29	1399	1655	JET, MAIN FUEL (.055)	OPT,OI		
30	27	28409	GASKET, MAIN FUEL JET	2,2,2,2		
31	1399	1985	NOZZLE, MAIN	2,2,2,2		#
31	1399	2785	NOZZLE, MAIN	,2,2		*
32	10	23178	SCREW, PLUG - MAIN NOZZLE	2,2,2,2		
33	24	26890	SPRING, THROTTLE SHAFT RE	1,1,1,1		
33	24	20869	SPRING, THROTTLE SHAFT RE	1,1,1,1		