



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1,1		
2	12	33001	WASHER, FLYWHEEL NUT	1,1,1,1		
3	28	20094	KEY, FLYWHEEL DRIVE	1,1,1,1		
4	400	1730	CRANKSHAFT	1,1,1,1		
5	25	29619	"O" RING, DRIVE SHAFT SPLINE	1,1,1,1		
6	500	1030A 1	CENTER MAIN BEARING ASSEM	1,1,1,1		
7	17	20032	DOWEL PIN, CENTER MAIN BE	2,2,2,2		
8	29	20046	BEARING, NEEDLE	28,28,2		
9		20047	RACE, OUTER	1,1,1,1		
10	53	20048	RING, SNAP - OUTER RACE	1,1,1,1		
11	10	28666	SCREW, CENTER MAIN BEARIN	2,2,2,2		
12	17	20379	DOWEL PIN, (STEPPED)	1,1,1,1		
13	534	2497A 2	MAIN BEARING ASSEMBLY ( VAL	2,2,2,2		
14	17	20032	DOWEL PIN, MAIN BEARING	20,20,2		
15	10	25313	SCREW, MAIN BEARING CLAMI	4,4,4,4		
16	11	29469	NUT, MAIN BEARING CLAMP	4,4,4,4		
17	34	30303A 1	REED SET, MATCHED - MAIN BE	2,2,2,2		
18	34	20053	REED STOP, MAIN BEARING RE	8,8,8,8		
19	10	29465	SCREW, REED STOP MOUNTING	8,8,8,8		
20	11	29469	NUT, REED STOP MOUNTING SC	8,8,8,8		
21	724	2537A 4	PISTON AND PISTON PIN ASSEM	4,4,4,4		
22	40	20057	LOCK RING, PISTON PIN	8,8,8,8		
23	39	27841	RING, PISTON	12,12,1		
24	600	7A 4	CONNECTING ROD AND CAP AS	4,4,4,4		
25	10	20060	SCREW, CAP TO CONNECTING	8,8,8,8		
26	11	20061	NUT, CONNECTING ROD SCRE	8,8,8,8		
27	29	20046	BEARING, NEEDLE - CRANKPIN	100,100		
28	29	20063	BEARING, NEEDLE - PISTON PI	88,88,8		
29	12	28121	WASHER, NEEDLE LOCATING	8,8,8,8		
--	724	2553A 3	PISTON AND PISTON PIN ASSEM	4,4,4,4		
--	39	28616A12	RING, PISTON (.015 OVERSIZE)	12,12,1		