



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1,1		
2	12	33001	WASHER, FLYWHEEL NUT	1,1,1,1		
3	28	20094	KEY, FLYWHEEL DRIVE	1,1,1,1		
4	223	2402A 2	FLYWHEEL ASSEMBLY	1...		
4	223	2402A 3	FLYWHEEL ASSEMBLY	,,1,		
4	223	2403A 5	FLYWHEEL ASSEMBLY	,,1,		
5	50	35817	RATCHET, FLYWHEEL - FLEX F	1...		
5	50	39837	RATCHET, FLYWHEEL - FLEX F	,,1,		
6	10	32417	SCREW, PLATE AND RATCHET	8,8,8,8		
7	10	26774	SCREW, FLEX PLATE TO FLYW	8,8,8,8		
8	17	26618	PIN, DOWEL - PULLEY TO FLYW	1,1,1,1		
9		29788	FLANGE, FLYWHEEL PULLEY	1,1,1,1		
10		30306	PULLEY, FLYWHEEL	1,1,1,1		
11		29787	HUB, FLANGE - FLYWHEEL PUI	1,1,1,1		
12	398	2171	STATOR, ALTERNATOR - FLYWF	,,1,		
13	10	32614	SCREW, STATOR TO UPPER EN	,,4,		
14	54	24836	CLAMP, STATOR LEAD TO CRAN	,,1,		
15	10	30009	SCREW, STATOR LEAD CLAMP F	,,1,		
16		22789	"D" WASHER, STATOR LEAD CL	,,1,		