



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2104	2654A 9	COWL FRONT COVER ASSEMBLY	1,1		
2		32361	KNOB, COWL FRONT COVER F	1,1		
3		30771	WASHER, COVER FASTENING	1,1		
4	12	27129	WASHER, COVER FASTENING	2,2		
5	24	32271	SPRING, TENSION - COVER FA	1,1		
6	17	29077	PIN, ROLL - TENSION SPRING	1,1		
7		38674	BLANKET, SOUND ABSORBING	1,1		
8		31095	SEAL, SOUND - LOWER SECTIO	2,2		
9		38133	SEAL, SOUND - UPPER SECTIC	1,1		
10	2118	2950A 2	WRAP AROUND COWL ASSEMBL	1,1		
11		38961	HANDLE, COWL LATCH EARLY	2,2		
12	17	21057	PIN, HINGE - COWL LATCH EA	4,4		
13	53	21058	"E" RING, COWL LATCH HINGE	4,4		
14		38964	SWIVEL, COWL LATCH EARLY	2,2		
15		46785A 1	COWL LATCH ASSEMBLY (LATE)	2,2		
16		30413	HOOK, COWL LATCH FASTENING	2,2		
17		37794	BLANKET, SOUND ABSORBING	1,1		
--	92	25234 1	GLUE (BLANKET ADHESIVE)	1,1		