



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	3015	CARBURETOR ASSEMBLY, COM	2,2		
2	1399	110A 1	FLOAT ASSEMBLY	2,2		
3	17	20853	PIN, FLOAT LEVER PINION	4,4		3
4	1399	102	LEVER, FLOAT (LOWER)	2,2		3
5	1399	101	LEVER, FLOAT (UPPER)	2,2		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	2,2		3
7	27	25033	GASKET, INLET SEAT	2,2		0
8	1399	99	GASKET, FLOAT BOWL COVER	2,2		0
9	1399	1133	COVER, FLOAT BOWL	2,2		
10	10	20854	SCREW, FLOAD BOWL COVER	2,2		
11	10	25850	SCREW, FLOAD BOWL COVER	2,2		
12	27	25851	GASKET, STRAINER COVER (L	2,2		0
13	1399	1754	SCREEN, FILTER	2,2		3
14	27	25849	GASKET, STRAINER COVER (S	2,2		0
15	1399	1135	COVER, STRAINER	2,2		
16	27	25848	GASKET, STRAINER COVER SC	2,2		0
17	10	25822	SCREW, STRAINER COVER FA	2,2		3
18	10	20847	SCREW, THROTTLE STOP LEV	2,2		3
19	1399	97	LEVER, THROTTLE STOP (SEE	2,2		
20	1399	2012	SHAFT, THROTTLE	2,2		
21	1399	3036	TUBE, IDLE	2,2		3
22	27	23180	GASKET, IDLE TUBE	2,2		0
23	10	20858	SCREW AND LOCKWASHER, T	4,4		3
24	1399	3037	SHUTTER, THROTTLE	2,2		
25	24	27160	SPRING, IDLE ADJUSTMENT S	2,2		3
26	1399	1713	SCREW, IDLE ADJUSTMENT	2,2		3
27	10	28405	SCREW, PLUG - MAIN FUEL JE	2,2		
28	27	28406	GASKET, JET CHANNEL PLUG	2,2		0
29	1399	1467	JET, MAIN FUEL (.067)	2,2		
29	1399	1465	JET, MAIN FUEL (.065) - STAND	2,2		3
29	1399	1463	JET, MAIN FUEL (.063)	OPT.,0		
29	1399	1461	JET, MAIN FUEL (.061)	OPT.,0		
30	27	28409	GASKET, MAIN FUEL JET	2,2		0
31	1399	2785	NOZZLE, MAIN	2,2		3
32	10	23178	SCREW, PLUG - MAIN NOZZLE	2,2		
33	24	26890	SPRING, THROTTLE SHAFT RE	1,1		3
33	24	20869	SPRING, THROTTLE SHAFT RE	1,1		3
34	10	28845	SCREW, PLUG - BODY CHANNE	2,2		
35	19	20011	WELCH PLUG, BODY CHANNEL	2,2		3
--	1399	1477	GASKET AND PACKING SET (1 PI	2,2		3
--	1399	2028	REPAIR PARTS KIT (1 PER CARB	2,2		