



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	394	2271A 2	MAGNETO ASSEMBLY, COMPLE	1		
2	45	27951	SHAFT, MAGNETO DRIVE	1		
3		39560A 1	MAGNETO PILOT ASSEMBLY	1		
4	30	20066	BALL BEARING, MAGNETO PILO	1		
5	24	27944	SPRING, HORSESHOE - MAGNET	1		
6	17	27962	PIN, ANCHOR - HORSESHOE SP	1		
7	12	29245	WASHER, HORSESHOE SPRING	1		
8		27946A 1	ECONOMIZER COLLAR AND PIN	1		
9	17	27961	PIN, ECONOMIZER COLLAR - S	1		
10	22	25094	FITTING, GREASE - ECONOMIZE	1		
11		38230A 1	THROTTLE ACTUATOR ASSEMB	1		
12	23	26602	BUSHING, NYLON - THROTTLE	1		
13	10	46420	SCRW, THROTTLE ACTUATOR T	2		
14		30043	ADAPTOR, MAGNETO	1		
15	22	25094	FITTING, GREASE - MAGNETO A	1		
16	12	27939	WASHER, MAGNETO PILOT	1		
17	14	27960	TAB WASHER, ADAPTOR CAP F	1		
18	13	27959	WASHER, WAVE - MAGNETO BA	1		
19		27955	CAP, MAGNETO ADAPTOR AND I	1		
20		27947	SWIVEL, LINKAGE - ECONOMIZE	1		
21		25996A 1	SWIVEL AND LINK ROD ASSEMB	1		
22	11	25168	NUT, UPPER LINK ROD ADJUSTI	1		
23		37700	ROD, LINK - UPPER	1		
24		27948	SWIVEL, UPPER LINK ROD TO T	1		
25		37688	LEVER, THROTTLE CONTROL	1		
26	10	34613	SCREW, THROTTLE LEVER TO E	1		
27	12	29395	WASHER, THROTTLE LEVER SC	2		
28	23	29529	BUSHING, THROTTLE LEVER SC	1		
29	24	37934	SPRING, QUICK DISCONNECT - T	1		
30	10	38069	SCREW, ANCHOR - QUICK DISCC	1		
31	10	30110	SCREW, ADAPTOR AND PILOT T	4		
32	10	22040	SCREW, ADAPTOR AND PILOT T	3		
33	12	20084	WASHER, ADAPTOR AND PILOT	3		
34	11	20083	NUT, ADAPTOR AND PILOT TO C	3		
35	28	28657	KEY, MAGNETO DRIVING	1		
36		29784	HUB, DRIVEN PULLEY	1		
37		29783A 1	DRIVEN PULLEY ASSEMBLY	1		
38	17	24873	PIN, ROLL - FLANGE LOCATING	2		
39		29785	FLANGE, DRIVEN PULLEY	1		
40	12	20138	WASHER, PULLEY CLAMPING SC	1		
41	10	29240	SCREW, PULLEY CLAMPING	1		