



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2117	2954	TOP COWL	1		
1	2117	2959A 2	TOP COWL ASSEMBLY	1		
2	16	21550	STUD, REAR - TOP COWL TO F	1		
3	16	21553	STUD, FRONT - TOP COWL TO	2		
4	25	20116	GROMMET, CHOKE KNOCKB - FF	1,1		
5		37690	SHIELD, REAR - TOP COWL	1,1		
6	10	37370	SCREW, REAR SHIELD TO TOP C	3,3		
7	13	37371	LOCKWASHER, REAR SHIELD SI	3,3		
8	12	21631	WASHER, REAR SHIELD SCREW	AR,AR		
9	13	35048	LOCKWASHER, TOP COWL STUI	1		
10	11	23161	NUT, TOP COWL STUD (3/8-24)	1		
11	12	20084	WASHER, TOP COWL STUD (5/1	AR,		
12	11	20102	NUT, TOP COWL STUD (5/16-24)	2		
13		46144	BRACKET, TOP COWL LATCH	2		
14	10	21091	SCREW, LATCH BRACKET TO TC	4		
15	12	29245	WASHER, LATCH BRACKET SCR	AR		
16	12	37998	WASHER, LATCH BRACKET SCR	AR		
17		46142A 1	RETAINER ASSEMBLY, TOP COV	1		
17		46142A 2	RETAINER ASSEMBLY, TOP COV	1		
18		35496	PAD, BUMPER - TOP COWL HAN	1,1		
19	10	24234	SCREW, RETAINER TO TOP COV	1,1		
20	13	39107	LOCKWASHER, RETAINER TO TI	1,1		
21		38431	BRACKET, REAR COWL SUPPOF	1,1		
22		37640	MOUNT, RUBBER - REAR SUPPC	1		
23	13	26993	LOCKWASHER, REAR SUPPORT	1		
24	12	26825	WASHER, REAR SUPPORT BRAI	1		
25	11	22053	NUT, REAR SUPPORT BRACKET	1		
26		37412	LEVER, CLAMPING - TOP COWL	2		
27	23	26819	BUSHING, TOP COWL CLAMPING	2		
28	23	31293	BUSHING, TOP COWL CLAMPING	2		
29	53	30428	FASTENER, TOP COWL CLAMPIN	2		
30	17	29077	PIN, ROLL - TOP COWL CLAMPIN	2		
31	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1		
32	14	20165	TAB WASHER, SHEAVE SHAFT	1		
33		37685	HOUSING, STARTER	1		
34	10	32565	SCREW, STARTER HOUSING TO	3		
35	13	20202	LOCKWASHER, STARTER HOUS	3		
36		37691	PLATE, CABLE GUIDE	1		
37	10	35881	SCREW, DRIVE - CABLE GUIDE F	3		
38		39835	RETAINER, STARTER SPRING	1		
39	24	29502A 1	SPRING, STARTER REWIND	1		