



| Parts List | | | | | | |
|------------|-------|--------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 30269A | FUEL PUMP ASSEMBLY | 1,1 | | |
| 2 | 21 | 30430A | CHECK VALVE ASSEMBLY | 1,1 | | |
| 3 | | 23014A | DIAPHRAGM KIT | 1,1 | | 4 |
| 4 | | | GASKET, CHECK VALVE TO | 2,2 | | 4 |
| 5 | | | GASKET, FUEL PUMP | 2,2 | | 4 |
| 6 | | | GASKET, FUEL PUMP COVE | 1,1 | | 4 |
| 7 | | 23004 | RETAINER, CHECK VALVE | 1,1 | | |
| 8 | 10 | 20037 | SCREW, RETAINER TO HOUSI | 2,2 | | |
| 9 | | 23008 | COVER, FUEL PUMP | 1,1 | | |
| 10 | 10 | 30274 | SCREW, FUEL PUMP MOUNTING | 2,2 | | |
| 11 | 10 | 29878 | SCREW, FUEL PUMP MOUNTING | 1,1 | | |
| 12 | 22 | 22949 | CONNECTOR, PUMP INLET TO F | 1,1 | | |
| 13 | 22 | 22946 | SLEEVE, RUBBER - CONNECTOF | 1,1 | | |
| 14 | 11 | 22948 | NUT, CONNECTOR TO FUEL LINI | 1,1 | | |
| 15 | 32 | 32094 | FUEL LINE, PUMP TO LOWER AN | 1,1 | | |
| 16 | 22 | 22995 | ELBOW, FUEL PUMP INLET | 1,1 | | |
| 17 | 22 | 22946 | SLEEVE, RUBBER | 1,1 | | |
| 18 | 11 | 22948 | NUT, ELBOW | 1,1 | | |
| 19 | 32 | 30036 | FUEL LINE, FUEL PUMP TO ADAF | 1,1 | | |
| 20 | 22 | 37682 | CONNECTOR, FUEL LINE TO ADA | ,1 | | |
| 21 | | 30186 | ADAPTTOR, CHECK UNIT (FUEL | 1,1 | | |
| 22 | | 30187 | STEM, CHECK UNIT ADAPTOR | 1,1 | | |
| 23 | 25 | 20415 | "O" RING, ADAPTOR STEM | 1,1 | | |
| 24 | 24 | 30189 | SPRING, ADAPTOR STEM | 1,1 | | |
| 25 | | 30188 | CUP WASHER, ADAPTOR | 1,1 | | |
| 26 | 10 | 37990 | SCREW, ADAPTOR TO BOTTOM | 2, | | |
| 26 | 10 | 21937 | SCREW, ADAPTOR TO BOTTOM | ,2 | | |
| 27 | 11 | 46887 | NUT, ADAPTOR SCREW | 2,2 | | |