



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	394	2271A 2	MAGNETO ASSEMBLY, COMPLE	1	
2	45	27951	SHAFT, MAGNETO DRIVE	1	
3		39560A 1	MAGNETO PILOT ASSEMBLY	1	
4	30	20066	BALL BEARING, MAGNETO PILO	1	
5	24	27944	SPRING, HORSESHOE - MAGNET	1	
6	17	27962	PIN, ANCHOR - HORSESHOE SP	1	
7	12	29245	WASHER, HORSESHOE SPRING	1	
8		27946A 1	ECONOMIZER COLLAR AND PIN	1	
9	17	27961	PIN, ECONOMIZER COLLAR - S	1	
10	22	25094	FITTING, GREASE - ECONOMIZE	1	
11		38230A 1	THROTTLE ACTUATOR ASSEMB	1	
12	23	26602	BUSHING, NYLON - THROTTLE	1	
13	10	46420	SCRW, THROTTLE ACTUATOR T	2	
14		30043	ADAPTOR, MAGNETO	1	
15	22	25094	FITTING, GREASE - MAGNETO A	1	
16	12	27939	WASHER, MAGNETO PILOT	1	
17	14	27960	TAB WASHER, ADAPTOR CAP F	1	
18	13	27959	WASHER, WAVE - MAGNETO BA	1	
19		27955	CAP, MAGNETO ADAPTOR AND I	1	
20		27947	SWIVEL, LINKAGE - ECONOMIZE	1	
21		25996A 1	SWIVEL AND LINK ROD ASSEMB	1	
22	11	25168	NUT, UPPER LINK ROD ADJUSTI	1	
23		37700	ROD, LINK - UPPER	1	
24		27948	SWIVEL, UPPER LINK ROD TO T	1	
25		37688	LEVER, THROTTLE CONTROL	1	
26	10	34613	SCREW, THROTTLE LEVER TO E	1	
27	12	29395	WASHER, THROTTLE LEVER SC	2	
28	23	29529	BUSHING, THROTTLE LEVER SC	1	
29	24	37934	SPRING, QUICK DISCONNECT - T	1	
30	10	38069	SCREW, ANCHOR - QUICK DISCC	1	
31	10	30110	SCREW, ADAPTOR AND PILOT T	4	
32	10	22040	SCREW, ADAPTOR AND PILOT T	3	
33	12	20084	WASHER, ADAPTOR AND PILOT	3	
34	11	20083	NUT, ADAPTOR AND PILOT TO C	3	
35	28	28657	KEY, MAGNETO DRIVING	1	
36		29784	HUB, DRIVEN PULLEY	1	
37		29783A 1	DRIVEN PULLEY ASSEMBLY	1	
38	17	24873	PIN, ROLL - FLANGE LOCATING	2	
39		29785	FLANGE, DRIVEN PULLEY	1	
40	12	20138	WASHER, PULLEY CLAMPING SC	1	
41	10	29240	SCREW, PULLEY CLAMPING	1	