



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	333	3213A 3	SWITCH BOX ASSEMBLY, COMPI	1,1,,1,1		
1	333	3213A 3	SWITCH BOX ASSEMBLY, COMPI	1,1,,1,1		*
1A	332	2986A 3	SWITCH BOX ASSEMBLY, COMPI	1,1,,1,1		
2	12	45075	WASHER, SWITCH BOX TERMIN	4,4,,4,4		
2	12	45075	WASHER, SWITCH BOX TERMIN	7(4),,		*
3	11	45076	NUT, SWITCH BOX TERMINAL	4,4,,4,4		
3	11	45076	NUT, SWITCH BOX TERMINAL	7(4),,		*
4	10	21722	SCREW, SWITCH BOX TO FRON	4,4,,4,4		
4	10	21722	SCREW, SWITCH BOX TO FRON	4,,		*
4	10	22485	SCREW, SWITCH BOX TO FRON	4,,		
5	13	22773	LOCKWASHER, SWITCH BOX FA	4,4,,4,4		
5	13	22773	LOCKWASHER, SWITCH BOX FA	4,,		*
6	11	46887	NUT, SWITCH BOX TO FRONT SI	4,,		
7	332	2910A 3	RECTIFIER ASSEMBLY, COMPLE	1,,		
8	12	45075	WASHER, RECTIFIER TERMINAL	3,,		
9	11	45076	NUT, RECTIFIER TERMINAL	3,,		
10	10	22485	SCREW, RECTIFIER TO FRONT S	2,,		
11	11	46887	NUT, RECTIFIER TO FRONT SUF	2,,		
12		49184	RECTIFIER STARTED WITH SEF	1,,1		
13	13	26993	LOCKWASHER, RECTIFIER TO	1,,1		
14	11	20922	NUT, RECITIFIER TO FRONT BI	1,,1		
15	23	28458	SPACER, RECTIFIER TO FRONT	1,,1		
16	10	29852	SCREW, RECTIFIER TERMINALS	3,,3		
17	11	29488	NUT, RECTIFIER TERMINALS	3,,3		
18	32	28373	SLEEVE, RECTIFIER TERMINALS	3,,3		
19		46280	BRACKET, RETAINER - HIGH TE	1,1,1,1		
20	10	24933	SCREW, RETAINER BRACKET TI	1,1,,1,1		
20	10	24933	SCREW, RETAINER BRACKET TI	1,,		*
20	10	21722	SCREW, RETAINER BRACKET TI	1,,		
21	23	33070	SPACER, RETAINER BRACKET T	1,1,,1,1		
21	23	33070	SPACER, RETAINER BRACKET T	1,,		*
22	11	46887	NUT, RETAINER BRACKET SCRE	1,1,1,1		
23	50	38890A 1	STARTER MOTOR ASSEMBLY	1,1,,1		
24	10	22698	SCREW, STARTER MOTOR TO C	2,2,2		
25	13	26993	LOCKWASHER, STARTER MOTO	2,2,2		
26		25596	WIRE, STARTER MOTOR TO STA	1,1,,1		
26		25596	WIRE, STARTER MOTOR TO STA	2(1),,		*
27	10	29197	SCREW, GROUND WIRE TO STA	1,1,,1		
28	13	26992	LOCKWASHER, GROUND WIRE I	1,1,,1		
--	11	20890	NUT, GROUND WIRE SCREW	1,1,,1		
29		22445	STARTER SOLENOID	1,1,1		