



IGNITION DRIVER AND PILOT ASSEMBLY

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	333	3144A 4	IGNITION DRIVE ASSEMBLY, COI	1	UNITED STATES 2858814 THRL	
1	333	4674A 3	IGNITION DRIVER ASSEMBLY, CI	1	UNITED STATES 3235063 AND I	
2	45	27951	SHAFT, IGNITION DRIVER	1		
3		47883A 1	PILOT ASSEMBLY, IGNITION DRI	1		
4	10	47910	SCREW, ADAPTOR AND PILOT T	4		
5	30	20066	BALL BEARING, IGNITION DRIVE	1		
6	24	27944	SPRING, HORSESHOE - IGNITION	1		
7	17	27962	PIN, ANCHOR - HORSESHOE SP	1		
8	12	29245	WASHER, HORSESHOE SPRING	1		
9		48103A 1	ECONOMIZER COLLAR AND PIN	1		
10	17	27961	PIN, ECONOMIZER COLLAR - S	1		
11	22	25094	FITTING, GREASE - ECONOMIZE	1		
12		48038	PLATE, THROTTLE ACTUATOR	1	UNITED STATES 2858814 THRL 0	
12		61124	PLATE, THROTTLE ACTUATOR	1	UNITED STATES 3235063 THRL	
12		66778	PLATE, THROTTLE ACTUATOR	1	UNITED STATES 3816308 AND I	
13	10	46420	SCREW, THROTTLE ACTUATOR	2		
14	10	23702	SCREW, ADJUSTING - THROTTL	1		
14	10	23015	SCREW, ADJUSTING - THROTTL	1		
15	11	20645	NUT, THROTTLE ACTUATOR AD	1		
16		48039	CAP, THROTTLE ACTUATOR AD	1		
17	12	46246	WASHER, IGNITION DRIVER PII	1		
18		30043A 1	ADAPTOR, IGNITION DRIVER	1	UNITED STATES 2858814 THRL	
19	10	22040	SCREW, ADAPTOR AND PILOT T	3		
20	12	20084	WASHER, ADAPTOR AND PILOT	3		
21	11	20083	NUT, ADAPTOR AND PILOT TO C	3	UNITED STATES 2858814 THRL	
18		66856A 1	ADAPTOR, IGNITIONA DRIVER	1	UNITED STATES 3816308 AND I 0	
19	10	37558	SCREW, ADAPTOR AND PILOT A	3		
20	12	20084	WASHER, ADAPTOR AND PILOT	3		
22	22	25094	FITTING, GREASE - IGNITION DR	1		
23	12	27939	WASHER, IGNITION DRIVER PII	1		
24	14	27960	TAB WASHER, ADAPTOR CAP FZ	1		
25	13	27959	WASHER, WAVE - IGNITION DRI	1		
26		27955	CAP, IGNITION DRIVER ADAPTO	1		
27	28	28657	KEY, IGNITION DRIVER	1		
28		29784	HUB, DRIVEN PULLEY	1		
--	23	29909	SPACER, DRIVEN PULLEY	1		
29		29783A 1	DRIVEN PULLEY ASSEMBLY	1		
30	17	24873	PIN, ROLL - FLANGE	2		
31		29785	FLANGE, DRIVEN PULLEY	1		
32	12	20138	WASHER, PULLEY SCREW	1		
33	10	48889	SCREW, PULLEY (5/8")	1		