



				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1			
2	14	20165	TAB WASHER, SHEAVE SHAFT N	1	UNITED STATES 2858814 THRL		
2	17	61004	TAB WASHER, SHEAVE SHAFT N	1	UNITED STATES 3235063 AND I		
3		57237	HOUSING, STARTER	1			
4	10	32565	SCREW, STARTER HOUSING TO	3			
5	13	20202	LOCKWASHER, STARTER HOUS	3			
6		37691	PLATE, CABLE GUIDE	1			
7	10	35881	SCREW, DRIVE - CABLE GUIDE	3			
8		39835	RETAINER, STARTER SPRING	1	UNITED STATES 2858814 THRL		
8		61002	RETAINER, STARTER SPRING	1	UNITED STATES 3235063 AND I		
9	24	39502A	1 SPRING, STARTER REWIND	1			
10	50	57094	SHEAVE ASSEMBLY	1	UNITED STATES 2858814 THRL		
11	23	28912	BUSHING, SPRING GUIDE	1	UNITED STATES 2858814 THRL		
10	50	62237A	1 SHEAVE ASSEMBLY	1	UNITED STATES 3478003 THRL		
11	23	63100	BUSHING, SPRING GUIDE	1	UNITED STATES 3478003 THRL		
10	50	66855A	1 SHEAVE ASSEMBLY	1	UNITED STATES 3816308 AND I		
11	23	63100	BUSHING, SPRING GUIDE	1	UNITED STATES 3816308 AND I		
12		30596	PAWL, STARTER	3			
13	13	36206	WASHER, WAVE - STARTER PAW	3			
14	23	28919	BUSHING, NYLON - SHEAVE SHA	1	UNITED STATES 2858814 THRL		
15	23	35560	SPACER, SHEAVE SHAFT	1	UNITED STATES 2858814 THRL		
15	23	61005	SPACER, SHEAVE SHAFT	1	UNITED STATES 3235063 THRL		
15	23	63061	SPACER, SHEAVE SHAFT (PART	1	UNITED STATES 3478003 AND I		
16		39840	RETAINER, WAVE WASHER	1			
17	12	57837	WASHER, WAVE WASHER RETA	1			
18	13	20160	WASHER, WAVE - RETAINER TE	1			
19	24	26088	SPRING, RETAINER PLATE TO S	1	UNITED STATES 2858814 THRL		
20		63101	PLATE, RETAINER - STARTER P	1	UNITED STATES 2858814 THRL		
19	24	66853	SPRING, RETAINER PLATE TO S	1	UNITED STATES 3816308 AND I		
19A		66848	RETAINER, SPRING	2	UNITED STATES 3816308 AND I		
20		66845	PLATE, RETAINER - STARTER P	1	UNITED STATES 3816308 AND I		
21	12	57860	WASHER, WEAR - SHEAVE SHAF	1	UNITED STATES 9008819 AND I		
22		45477	SHAFT, SHEAVE	1	UNITED STATES 2858814 THRL		
22		61003	SHAFT, SHEAVE	1	UNITED STATES 3235063 AND I		
23	50	28985A	1 STARTER CABLE ASSEMBLY	1			
23		47341A	1 STARTER CABLE (FOR MANUAL	1			
24		28747	HANDLE, STARTER CABLE	1			
25		28748	RETAINER, STARTER CABLE AN	1			
26		57041A	1 CABLE ASSEMBLY, INTERLOCK	1			
27	10	32228	SCREW, INTERLOCK CABLE TO I	1			
28	10	20100	SCREW, INTERLOCK CABLE TO I	1			