



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	831	5347A 3	CYLINDER BLOCK AND CRANKC	1	
2	1100	3281A 1	END CAP ASSEMBLY, UPPER	1	
3	26	29476	OIL SEAL	1	
4	25	20081	"O" RING, UPPER END CAP	1	4
5	30	20080	BALL BEARING, UPPER END C	1	
6	15	20082A 1	SHIM, UPPER END CAP TO CYL.	AP	
7	10	29256	SCREW, UPPER END CAP MONT	4	
8		37639	MOUNT, RUBBER - CRANKCASE	2	
9	11	46887	NUT, CRANKCASE RUBBER MOL	4	
10		37996	GROUND STRAP, CRANKCASE M	1	
11	1158	5302A 1	END CAP ASSEMBLY, LOWER	1	
13	26	29476	L, LOWER END CAP	2	
14	25	20081	"O" RING, LOWER END CAP	1	4
15	30	20080	BALL BEARING, LOWER END C	1	
16	15	20085A 1	SHIM, LOWER END CAP TO CRA	AP	
17	10	29256	SCREW, LOWER END CAP MOUN	3	
18	27	46110	GASKET, CYLINDER BLOCK TO E	1	4
19		46109	PLAT, BAFFLE - EXJAUST MANIF	1	
20	27	46111	GASKET, BAFFLE PLATE TO EXH	1	4
21		46112	COVER, EXHUAST MANIFOLD	1	
22	10	37562	SCREW, MANIFOLD COVER TO C	12	
23	10	38837	SCREW, MANIFOLD COVER TO C	3	
24	54	52905	CLIP, HIGH TENSION LEAD	2	
25	1017	4002A 1	COVER ASSEMBLY, CYLINDER B	1	
26	22	32802	PLUG, PIPE - CYLINDER BLOCK	1	
27	27	37816	GASKET, CYLINDER BLOCK COV	1	4
28	10	20653	SCREW, CYLINDER BLOCK COVE	10	
29		87	NUT, COVER MOUNTING SCREW	10	
30		37639	MOUNT, RUBBER - CYLINDER BL	1	
31	11	46887	NUT CYLINDER BLOCK COVER F	2	
32		27935	COVER, TRANSFER PORT	2	
33	27	27936	GASKET, TRANSFER PORT COVI	2	4
34	10	20540	SCREW, TRANSFER PORT COVE	6	