



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1554	4813A 2	DRIVE SHAFT HOUSING ASSEM	1	
1	1564	4812A 2	DRIVE SHAFT HOUSING ASSEM	1	
2	19	64649	PLUG, PLASTIC - TRIM TAB SCI	1	
3	16	57932	STUD, DRIVE SHAFT HOUSING	1	
4	16	57935	STUD, DRIVE SHAFT HOUSING	1	
5	11	34933	NUT, GEAR HOUSING TO DRIVE	2	
6	12	65791	WASHER, GEAR HOUSING TO D	2	
7		47835	ROD, PUSH - REVERSE LOCK (S)	1	
7		47836	ROD, PUSH - REVERSE LOCK (L)	1	
8	11	28770	NUT, JAM - PUSH ROD	1	
9		47837	ROD END, PUSH ROD	1	
10	17	39023	PIN, REVERSE LOCK LEVER	1	
11	18	25191	COTTER PIN, PUSH ROD TO REV	1	
12		52917	GUIDE, PUSH ROD	1	UNITED STATES 4141000 THRI
12		69786	GUIDE, PUSH ROD	1	UNITED STATES 4280270 AND 0
13		35474	COVER, LOWER MOUNT CLAMP	2	
14	10	29722	SCREW, COVER TO LOWER MOU	2	
15	11	35521	NUT, LOWER MOUNT CLAMP CC	2	
16		69592	CLAMP, LOWER MOUNT TO DRP	2	
17	10	29256	SCREW, LOWER MOUNT CLAMP	4	
18	24	35522	SPRING, TENSION - LOWER MOU	4	
19		37395	MOUNT, RUBBER - LOWER	2	
20		25067	BUMPER, RUBBER - LOWER MO	2	
21	10	49318	SCREW, LOWER MOUNT SCREW	2	
22	12	28051	WASHER, LOWER MOUNT SCREW	2	
23	12	28053	WASHER, RUBBER - LOWER MO	2	
24	12	30119	WASHER, LOWER MOUNT SCREW	2	
25	11	25096	NUT, LOWER MOUNT SCREW	2	
26		37394	MOUNT, RUBBER - UPPER	2	
26A	25	65936	"O" RING, UPPER MOUNT	2	0
27		24929	PACKING, "U" CUP - UPPER MOU	2	
28		24935	COVER, UPPER MOUNT - OUTSII	2	
29		31120	COVER, UPPER MOUNT - INSIDE	2	
30	10	49987	SCREW, UPPER MOUNT COVER	4	
31	10	49988	SCREW, UPPER MOUNT COVER	4	
32	11	69431	NUT, UPPER MOUNT COVER FA	8	
33	12	27727	WASHER, UPPER MOUNT BOLT	2	
34	12	66966	WASHER, RUBBER - UPPER MOU	2	
35	12	30519	WASHER, UPPER MOUNT BOLD	2	
36	11	23161	NUT, UPPER MOUNT BOLT	2	
37	27	28501	GASKET, EXHAUST EXTENSION	1	0