



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1		
2	12	68229	WASHER, FLYWHEEL NUT	1		
3	28	20094	KEYWHEEL DRIVE	1		
4	223	2402A13	FLYWHEEL ASSEMBLY (MANUAL)	1		0
4	223	2403A18	FLYWHEEL ASSEMBLY (ELECTR)	1		0
5	50	65211	RATCHET, FLYWHEEL (MANUA	1		
6	10	69088	SCREW, PLATE AND RATCHET	8		
7	10	32417	SCREW, FLEX PLATE TO FLYW	8		
8	17	26618	PIN, DOWEL - PULLEY TO FLYWI	1		
9		29788	FLANGE, FLYWHEEL PULLEY	1		
10		30306	PULLEY, FLYWHEEL	1		
11		29787	HUB, FLANGE - FLYWHEEL PUI	1		
12	398	2996	STATOR, ALTERNATOR - FLYWH	1		
13	10	57021	SCREW, STATOR TO UPPER EN	4		
14	54	26550	CLAMP, STATOR LEAD TO CRAN	1		
15	10	35519	SCREW, STATOR LEAD CLAMP F	1		
16		22789	"D" WASHER, STATOR LEAD CL	1		
17	54	46379	CLIP, STATOR LEAD TO CRANKC	1		