



| Parts List | | | | | |
|------------|-------|----------|-----------------------------|-----|----------|
| Ref | Class | Part | Description | Qty | Footnote |
| 1 | 333 | 3213A 3 | SWITCH BOX ASSEMBLY, COMPI | 1 | |
| 2 | 11 | 45076 | NUT, SWITCH BOX TERMINAL | 4 | |
| 3 | 10 | 69030 | SCREW, SWITCH BOX TO FRON | 4 | |
| 4 | | 49184 | RECTIFIER ELECTRIC ELECTRIC | 1 | |
| 5 | 13 | 26993 | LOCKWASHER, RECTIFIER TO | 1 | |
| 6 | 11 | 28770 | NUT, RECTIFIER TO FRONT BF | 1 | |
| 7 | 23 | 28458 | SPACER, RECTIFIER TO FRONT | 1 | |
| 8 | 10 | 20055 | SCREW, RECTIFIER TERMINALS | 3 | |
| 9 | 11 | 29488 | NUT, RECTIFIER TERMINALS EL | 3 | |
| 10 | 32 | 28373 | SLEEVE, RECTIFIER TERMINALS | 3 | |
| 11 | | 59757 | BRACKET, RETAINER - HIGH TE | 1 | |
| 12 | 10 | 49987 | SCREW, RETAINER BRACKET TI | 1 | |
| 13 | 11 | 35045 | NUT, RETAINER BRACKET SCRE | 1 | |
| 14 | 50 | 55601 | STARTER MOTOR ASSEMBLY EL | 1 | |
| 15 | 10 | 52446 | SCREW, STARTER MOTOR TO C | 2 | |
| 16 | 13 | 26993 | LOCKWASHER, STARTER MOTO | 2 | |
| 17 | 84 | 71441 | WIRE, STARTER MOTOR TO SOI | 1 | 0 |
| 18 | 10 | 29197 | SCREW, GROUND WIRE TO STA | 1 | |
| 19 | 13 | 26992 | LOCKWASHER, GROUND WIRE I | 1 | |
| 20 | 11 | 20890 | NUT, GROUND WIRE SCREW EL | 1 | |
| 21 | 89 | 68258 | STARTER SOLENOID ELECTRIC | 1 | 0 |
| 22 | 13 | 26996 | LOCKWASHER, SOLENOID TERK | 2 | |
| 23 | 11 | 68219 | NUT, SOLENOID TERMINAL (#10 | 2 | |
| 24 | 13 | 26993 | LOCKWASHER, SOLENOID TERK | 2 | |
| 25 | 11 | 26062 | NUT, CAP - SOLENOID TERMINA | 2 | |
| 26 | | 46265 | BOOT, TERMINAL - STARTER SC | 1 | |
| 27 | 10 | 28635 | SCREW, SOLENOID TO SUPPOR | 2 | |
| 28 | 13 | 26992 | WASHER, STARTER SOLENOID | 2 | |
| 29 | 84 | 65773A 2 | GROUND STRAP ASSEMBLY ELE | 1 | 0 |
| 30 | 84 | 71443 | WIRING HARNESS (INTERNAL) E | 1 | 0 |
| 31 | 24 | 28975 | SPRING, GARTER - INTERNAL w | 1 | |
| 32 | 54 | 52876 | CLAMP, WIRING HARNESS ELEC | 1 | |
| 33 | 10 | 45862 | SCREW, WIRING HARNESS CLAI | 2 | |
| 34 | 13 | 26996 | LOCKWASHER, WIRING HARNE | 2 | |
| 35 | 12 | 20128 | WASHER, WIRING HARNESS CL | 2 | |
| 36 | | 61990 | STA-STRAP, WIRING HARNESS I | 1 | |
| 37 | 332 | 4895A 2 | IGNITION COIL ASSEMBLY | 1 | 0 |
| 38 | | 72015 | PAD, RUBBER - IGNITION COIL | 1 | 0 |
| 39 | | 63195 | COVER, CASTING - COIL | 1 | |
| 40 | 10 | 64099 | SCREW, IGNITION COIL TO BRA | 3 | |
| 41 | 12 | 26996 | LOCKWASHER, IGNITION COIL S | 2 | |