



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2116	3643A	1 BOTTOM COWL ASSEMBLY	1	UNITED STATES 2858814 THRL	
1	2116	4381A	1 BOTTOM COWL ASSEMBLY	1	UNITED STATES 9008819 AND I	
2		57786	COVER, PLUG - BOTTOM COWL	1	REMOVE - NOT REQUIRED ON I	
3	10	45862	SCREW, PLUG COVER TO BOT	2	REMOVE - NOT REQUIRED ON I	
4	13	26996	LOCKWASHER, PLUG COVER	2	REMOVE - NOT REQUIRED ON I	
-	12	20128	WASHER, PLUG COVER SCREW	2	REMOVE - NOT REQUIRED ON I	
5	16	20467	STUD, BOTTOM COWL TO REA	4		
6	11	20361	NUT, BOTTOM COWL STUD	4		
7	32	34395A	1 TUBE, VENT - IGNITION DRIVER	1		
7	32	34395A	1 TUBE, VENT DISTRIBUTOR OUT	1	UNITED STATES 2858814 THRL	
8	22	31521	ELBOW, VENT TUBE TO BOTTO	3	UNITED STATES 2858814 THRL	
9		47764	STRAP, VENT HOSE	1	UNITED STATES 2858814 THRL	
--	54	49218	CLAMP, VENT HOUSE	1	UNITED STATES 2858814 THRL	
--	10	21722	SCREW, VENT HOUSE CLAMP (5	1	UNITED STATES 2858814 THRL	
--	11	46887	NUT, VENT HOSE CLAMP SCREW	1	UNITED STATES 2858814 THRL	
10		48035A	1 STOP SWITCH ASSEMBLY-MANI	1	UNITED STATES 2858814 THRL	
11		30859	INSULATOR, SLEEVE - INNER	1	MANUAL UNITED STATES 2858	
12	24	30858A	1 SPRING AND CONTRACT ASSE	1	UNITED STATES 2858814 THRL	
13		38950A	1 COVER ASSEMBLY, STOP SWIT	1	UNITED STATES 2858814 THRL	
14	12	38949	WASHER, SEALING - STOP SW	1	UNITED STATES 2858814 THRL	
15	13	21972	LOCKWASHER, CONNECTOR BA	1	UNITED STATES 2858814 THRL	
16	11	21971	NUT, CONNECTOR BASE TO BO	1	UNITED STATES 2858814 THRL	
17		59065A	4 STOP SWITCH ASSEMBLY-MANI	1	UNITED STATES 3235063 AND I	
18	24	60239	1 SPRING, STOP SWITCH-MANL	1	UNITED STATES 3235063 AND I	
19	87	61577A	1 CONTRACT ASSEMBLY, STOP	1	UNITED STATES 3235063 AND I	
20		38950A	1 COVER ASSEMBLY, STOP SWITC	1	UNITED STATES 3235063 AND I	
21	12	59061	1 WASHER, STOP SWITCH-MANU	1	UNITED STATES 3235063 AND I	
22	13	26996	1 LOCKWASHER, STOP SWITCH-M	1	UNITED STATES 3235063 AND I	
23	11	20645	1 NUT, GROUP LEAD TO STOP SW	1	UNITED STATES 3235063 AND I	
24	13	21972	1 LOCKWASHER, CONNECTOR BA	1	UNITED STATES 3235063 AND I	
25	11	21971	1 NUT, CONNECTOR BASE TO BO	1	UNITED STATES 3235063 AND I	
26		56319A	5 WIRE, SWITCH BOX TO STOP SW	1	UNITED STATES 3235063 AND I	
27		37943A	1 COVER PLATE ASSEMBLY	1	UNITED STATES 2858814 THRL	
28		37944	1 PAD, SOUND - COVER PLATE	1	UNITED STATES 2858814 THRL	
27		60948A	1 COVER PLATE ASSEMBLY	1	UNITED STATES 3235063 AND I	
29	10	30663	3 SCREW, COVER PLATE TO BOT	3		
30		37695	1 BOOT, CONTROL CABLE	1		
31		23760	1 BAFFLE, BOTTOM COWL	1	UNITED STATES 2858814 THRL	
32	10	52867	3 SCREW, BAFFLE TO BOTTOM CC	3	UNITED STATES 2858814 THRL	
33		37637	1 BOOT, FUEL CONNECTOR	1		
34		27692	1 SUPPORT, EXTERNAL WIRING L	1		