



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1626	3927A 4	GEAR HOUSING ASSEMBLY, CO	1	SEE NOTE BELOW UNITED STA	
-	1626	3927A 5	GEAR HOUSING ASSEMBLY, CO	1	SEE NOTE BELOW UNITED STA	
-	1643	4518A 7	GEAR HOUSING ASSEMBLY, CO	1	SEE CHART. SEE NOTE BELOW	
-	1643	4518A 8	GEAR HOUSING ASSEMBLY, CO	1	SEE CHART. SEE NOTE BELOW	
-	1643	4814A10	GEAR HOUSING ASSEMBLY, CO	1	SEE CHART. SEE NOTE BELOW	
-	1643	4814A11	GEAR HOUSING ASSEMBLY, CO	1	SEE CHART. SEE NOTE BELOW	
-	1643	4931A 9	GEAR HOUSING ASSEMBLY, CO	1	SEE NOTE BELOW UNITED STA	
-	1643	4931A10	GEAR HOUSING ASSEMBLY, CO	1	SEE NOTE BELOW UNITED STA	
1	1626	3927A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE 34 FOR BREAKDOWN	
1	1643	4518A 6	GEAR HOUSING ASSEMBLY-FI	1	SEE PAGE 34 FOR BREAKDOWN	
1	1643	4814A 9	GEAR HOUSING ASSEMBLY-FI	1	SEE PAGE 34 FOR BREAKDOWN	
1	1643	4931A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE 34 FOR BREAKDOWN	
52		36288	CAM, SHIFT	1	UNITED STATES 2858814 THRL	
52		54346	CAM, SHIFT	1	UNITED STATES 3816308 AND I	
53		38441	FOLLOWER, CAM	1		
54		20843	SLIDE, CROSS PIN	1		
55	24	39845	SPRING, COMPRESSION - CAM	1		
56	15	38374A 1	SHIM, BEARING CUP TO GEAR	AR		
57	31	38356A 1	TAPERED ROLLER BEARING A	1		
58	31	21739	BEARING, ROLLER - FORWARD	1		
59	43	55608	FORWARD GEAR ASSEMBLY	1		
60	52	47586	RATCHET, SLIDING CLUTCH	1		
61	17	38113	PIN, CROSS - RATCHET TO PR	1		
62	24	38114	SPRING, RETAINING - CROSS	1		
63	44	55911	SHAFT, PROPELLER	1		
64	43	55609	REVERSE GEAR ASSEMBLY	1	UNITED STATES 2858814 THRL	
64	43	66554	REVERSE GEAR ASSEMBLY	1	UNITED STATES 3816308 AND I	
65	15	20927A 1	SHIM, TTHRUST WASHER TO	AR		
66	12	32004	WASHER, THRUST - REVERSE	1		
67	30	20839	BEARING, BALL - REVERSE GE	1		
68	25	31986	"O" RING, BEARING CARRIER	1		2, 4
69		55904A 1	BEARING CARRIER ASSEMBLY	1		
70	31	21700	BEARING ROLLER - BEARING	1		
71	26	56788	OIL SEAL, BEARING CARRIER	1		
72	28	30281	KEY, LOCATING - BEARING CA	1		
73	14	53012	TAB WASHER, GEAR HOUSING	1		
74		53013	COVER, GEAR HOUSING	1		
75		31640A 1	TRIM TAB ASSEMBLY, GEAR H	1		
76	10	55726	SCREW, TRIM TAB TO GEAR H	1		
77	12	45175	WASHER, DRIVE SHAFT HOUS	1		
78	11	24862	NUT, DRIVE SHAFT HOUSING	1		