



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1333	5818	CARBURETOR ASSEMBLY, COMI	2	UNITED STATES 4141000 THRL	
1	1333	5921	CARBURETOR ASSEMBLY, COMI	2	UNITED STATES 4280270 AND I	
2	1399	110A 1	FLOAT ASSEMBLY	2		
3			PIN, FLOAT LEVER PINION	4		3
4			LEVER, FLOAT (LOWER)	2		3
5			LEVER, FLOAT (UPPER)	2		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	2		
7			GASKET, INLET SEAT	2		3,0
8			GASKET, FLOAT BOWL COVER	2		3,0
9	1399	1133	COVER, FLOAT BOWL	2	UNITED STATES 4141000 THRL	
9	1399	6223	COVER, FLOAT BOWL	2	UNITED STATES 4280270 AND I	
9A			HOSE, ECONOMIZER	2	UNITED STATES 4280270 AND I	3
9B	1399	6126	JET, ECONOMIZER (.086)	2	UNITED STATES 4280270 AND I	
10	10	52195	SCREW, FLOAT BOWL COVER	2		
11	10	52196	SCREW, FLOAT BOWL COVER	2		
12	13	26995	LOCKWASHER, FLOAT BOWL C	4		
13	27	25851	GASKET, STRAINER COVER (L	2		3,0
14	1399	3938	SCREEN, FILTER	2		3
15	27	25849	GASKET, STRAINER COVER (SM	2		3,0
16	1399	1135	COVER, STRAINER	2		
17			GASKET, STRAINER COVER SC	2		3,0
18			SCREW, STRAINER COVER FA	2		3
19	10	20847	SCREW, THROTTLE STOP LEVE	2		3
20	1399	94	LEVER, THROTTLE STOP(SEE	2		
21	1399	2012	SHAFT, THROTTLE	2		
22			TUBE, IDLE	2		3
23			GASKET, IDLE TUBE	2		3,0
24			SCREW AND LOCKWASHER, TH	4		3
25	1399	3392	SHUTTER, THROTTLE	2	UNITED STATES 4141000 THRL	
25	1399	5812	SHUTTER, THROTTLE	2	UNITED STATES 4280270 AND I	
26			SPRING, IDLE ADJUSTMENT S	2		3
27			SCREW, IDLE ADJUSTMENT	2		3
28	10	28405	SCREW, PLUG - MAIN FUEL JE	2		
29			GASKET, JET CHANNEL PLUG S	2		3,0
30	1399	1465	JET, MAIN FUEL (.065) - STAND	OPT.	UNITED STATES 4280270 AND	
30	1399	1465	JET, MAIN FUEL (.063) - STAND	2	UNITED STATES 4141000 THRL	
30	1399	1461	JET, MAIN FUEL (.061)	OPT.		
30	1399	1459	JET, MAIN FUEL (.059)	OPT.		
32			NOZZLE, MAIN	2		3
33	10	23178	SCREW, PLUG - MAIN NOZZLE	2		
34			SPRING, THROTTLE SHAFT RE	2		