



EXHAUST PLATE

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		19653A 3	EXHAUST PLATE ASSEMBLY	1		3
2	21	817519A 1	CHECK VALVE	1		
3	17	23784	DOWEL PIN	4		
4		812893	UPPER MOUNT	1		
5	10	40011153	SCREW (M8 X 45)	4		
6	10	42973	SCREW (M12 X 154)	2		
7	12	93416 1	WASHER	2		
8	12	28421	WASHER	2		
9	11	90099	NUT	2		
10	10	40011158	SCREW (M8 X 70)	1		
11	27	812866	GASKET	1	NOT USED ON JET MODELS	5
12	23	48237	BUSHING	1	NOT USED ON JET MODELS	
13		815639A 8	SHIFT SHAFT	1	(UPPER)(SHORT) NOT USED ON	3
13		812891A 6	SHIFT SHAFT	1	(UPPER)(LONG - ELECTRIC) NO	3
13		815639A 7	SHIFT SHAFT	1	(UPPER)(LONG/LL - MANUAL) N	3
14		812872A 1	SHIFT LINK	1	NOT USED ON JET MODELS	
14		812872A 2	SHIFT LINK	1	(BIGFOOT) NOT USED ON JET M	3
15	23	48475	BUSHING	1	NOT USED ON JET MODELS	
16	11	826833 6	NUT	1	NOT USED ON JET MODELS	
17	32	43014 4	WATER TUBE	1	(SHORT)	
17	32	43014 3	WATER TUBE	1	(LONG)	
18	25	93221	GROMMET	1		5
19		19655 1	EXHAUST TUBE	1		
20	10	40011153	SCREW (M8 X 45)	4		
21		812886	SEAL	1		
22		99019	CLAMP	1		
23		42941	SEAL (UPPER)	1		5
24	10	40011155	SCREW (M8 X 55)	2		
-	27	812867A97	GASKET SET	1		