



8128

| Parts List | | | | | | |
|------------|-------|------------------------|------------------|-----|----------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 11 | 16071 | NUT | 1 | | |
| 2 | 12 | 16072 | WASHER | 1 | | |
| 3 | 262 | 803557T | FLYWHEEL | 1 | | |
| 4 | 54 | 16060 | CLAMP | 1 | | |
| 5 | 10 | 16821 | SCREW | 1 | | |
| 6 | | 803844T | EXCITER COIL | 1 | | |
| 7 | 10 | 16059 | SCREW | 2 | | |
| 8 | 339 | 803559T 1 | IGNITION COIL | 1 | | |
| 9 | 85 | 803560 | BOOT | 1 | | |
| 10 | 10 | 16705 1 | BOLT, (M6 x 20) | 2 | | |
| 11 | | 878062 | DAMPER | 1 | | |
| 12 | | 803558T 1 | CD UNIT | 1 | SN# 0R036271 & Below | |
| 12 | | 803558T02 | CD UNIT | 1 | SN# 0R036272 & Up | |
| 13 | | 878061 | FRONT DAMPER | 1 | | |
| 14 | 23 | 879705 | SLEEVE | 1 | | |
| 15 | 54 | 803563 | CLAMP | 1 | (67MM) | |
| 15 | 54 | 803563 1 | CLAMP | 1 | (87MM) | |
| 15 | 54 | 95306 | CLAMP | 1 | (47.5MM) | |
| 15 | 54 | 813275 | CLAMP | 1 | (80 MM) | |
| 16 | 10 | 16827 | SCREW | 1 | | |
| 17 | | 803562 | WARNING LAMP | 1 | | |
| 18 | 87 | 823037A 3 | STOP SWITCH | 1 | SN# 0R036271 & Below | |
| 18 | 87 | 823037A05 | STOP SWITCH | 1 | SN# 0R036272 & Up | |
| 19 | | 823054 | LANYARD | 1 | | |
| 20 | 25 | 16068 | GROMMET | 1 | | |
| 21 | | 803561 | PULSER COIL | 1 | | |
| 22 | 10 | 823031 10 | SCREW, (M5 x 16) | 2 | | |