



4953

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		42207A	STARTER ASSEMBLY, Recoil	1		
1		42207	HOUSING, Starter	1		
2		42690	BUSHING	1		
3	53	818853	RING, Retaining	1		
4	24	86857	SPRING	1		
5		42034A	STARTER PULLEY	1		
6	50	850057	ROPE, Starter	1		
7	24	86851	SPRING	2		
8		86850	CAM	2		
9	53	86849	RING, Retaining	2		
10	24	86852	SPRING	1		
11		86853	CAM	1		
12	10	826253	SCREW, (.250-20 x .625)	1		
13		833161	FELT PAD	1		
14		19018	REST	1		
15	23	30977	SPACER	4		
16		12674	SUPPORT	1		
17	10	40019111	SCREW, (M5 x 35)	2		
18	11	40138	NUT, (M5)	2		
19		42171	LEVER (Upper)	1		
20	12	56681	WASHER, (.203 x .500 x .032)	1		
21		42173	LEVER (Lower)	1		
22	10	48408	SCREW, (#10-16 x .500)	1		
23	10	40011128	SCREW, (M6 x 20)	3		
24		85174A	HANDLE ASSEMBLY	1		
25		NSS	NOT SOLD SEPARATE (Retaine	1		
26		NSS	NOT SOLD SEPARATE (Decal-Sea	1		
27	37	827282	DECAL, Warning, High Voltage	1		
28		NSS	NOT SOLD SEPARATE (Decal-Em	1		