



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1392	9503A11	CARBURETOR (6)(WMC-20B)	1	
1	1392	9266A12	CARBURETOR (8)(WMC-18B)	1	
1	1392	8846A14	CARBURETOR (9.9)(WMC-23)	1	
2	1395	9473	THROTTLE VALVE	1	
2		815133	THROTTLE VALVE (WMC-23)	1	
3	195	9472	THROTTLE SHAFT (WMC-17/18)	1	
3	1395	9698	SHAFT (WMC-17C/18A/18B/20A)	1	
3		813022	SHAFT (WMC-23)(INCL.SCREW)	1	
4	1395	9164	FUEL BOWL	1	
5	1395	9169	FLOAT	1	
6	1395	9855	INLET NEEDLE VALVE	1	
7	1399	5315	MAIN FUEL JET (.042)(6)	1	
7	1399	5317	MAIN FUEL JET (.046)(8)	1	
7	1399	5213	MAIN FUEL JET (.056)(9.9)	1	
7	1395	6359	MAIN FUEL JET (.052)(9.9)	1	
8	1395	9171	PLUG, JET RETAINER	1	
9		813618	COVER, DIAPHRAGM	1	
10	1395	9174	SCREW (WMC-17/18/20)	4	
10	1395	9697	SCREW (WMC-17B/17C/18A/18B)	4	
11		15827A 1	FUEL PUMP KIT	1	
12	1395	9643	SCREW, FUEL PUMP COVER	5	
13	1395	9177	PLATE (WMC-17/18/20)	1	
13	1395	9699	PLATE (WMC-17B/17C/18A/18B)	1	
14	1395	9172	SCREW (WMC-17/18/20)	2	
14	1395	9696	SCREW (WMC-17B/17C/18A/18B)	2	
15	1395	9725	GASKET/DIAPHRAGM KIT	1	
16	1395	9648	REPAIR PARTS KIT	1	
16		813023	REPAIR PARTS KIT(WMC-23)	1	
17	1395	9637	COVER, FUEL PUMP	1	
18	1395	9762	PLUG	1	
19	27	19206 1	GASKET, CARBURETOR	1	2
19A	1395	9635	DIAPHRAGM	1	
20		44554 1	IDLE WIRE	1	
21		12805 3	FAST IDLE LEVER	1	
22		12803	PRIMER BRACKET	1	
23	11	97877	PUSHNUT	1	
24	10	79964	SCREW	1	
25	24	11277	SPRING	1	
26	10	40056110	SCREW(M5X 8X 30)	2	
26	10	40001 8	SCREW(M5X 8X 12)	2	
27	10	78965	SCREW	1	