



19262

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	462	8839A 2	CRANKSHAFT ASSEMBLY	1		
2	30	64424	BEARING, BALL - LOWER AND	2		
3	15	22369A 1	SHIM, LOWER BEARING TO CRA	AR		
4	542	7509A 3	MAIN BEARING ASSEMBLY (VAL)	2		
5	17	20032	DOWELL PIN, MAIN BEARING	4		
6	17	60282	PIN, Dowel (STEPPED)	2		
7	17	65855	PIN, Dowel, REED STOP	16		
8	34	66051A 1	REED SET, MATCHED - MAIN B	2		
9	34	65946	REED STOP	8		
10	10	77280	SCREW, (.190-32 X .56), REED	8		
11	11	20110	NUT, (#10-32), REED STOP MO	8		
12	10	38055	SCREW, (.190-32 X .62), MAIN B	4		
13	11	20110	NUT, (#10-32), MAIN BEARING	4		
14		26113	RACE, OUTER (PAIR)	2		
15	53	26933	SNAP RING, SNAP - OUTER F	2		
16	29	71422	NEEDLE BEARING	112		
17	774	8600A 3	PISTON/PISTON PIN	3	(Standard)(50)	
17	774	9095A 1	PISTON/PISTON PIN	AR	(.015 Oversize)(50)	
17	774	9096A 1	PISTON/PISTON PIN	AR	(.030 Oversize)(50)	
17	776	8896A 3	PISTON/PISTON PIN	3	(Standard)(60)	
17	776	8897A 2	PISTON/PISTON PIN	AR	(.015 Oversize)(60)	
17	776	8898A 2	PISTON/PISTON PIN	AR	(.030 Oversize)(60)	
18	40	52035	RING, Lock, PISTON PIN	6		
19	39	78816A12	RING, PISTON	1	(STANDARD)	
19	39	78811A12	RING, PISTON	AR	(.015 Oversize)	
19	39	88392A12	RING	AR	(.030 Oversize)	
20	624	8101A 3	CONNECTING ROD AND CAP AS:	3		
21	10	91012	SCREW, (.25-28), CAP TO CONN	6		
22	31	62596A 1	BEARING ASSEMBLY	3		
23	29	47270	BEARING, NEEDLE - PISTON PI	87		
24	12	47247	WASHER, NEEDLE LOCATING	6		