



DRIVE SHAFT HOUSING

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3516	816528A 1	DRIVESHAFT HOUSING (SHORT)	1		
1	3516	816528A 2	DRIVESHAFT HOUSING (SHORT)	1		
1	3510	9864A 6	DRIVESHAFT HOUSING (LONG)	1		
1	3510	9864A 7	DRIVESHAFT HOUSING (LONG)	1		
1	3510	9864A 5	DRIVESHAFT HOUSING (LONG)	1		
1	3516	816528A 3	DRIVESHAFT HOUSING (JET 45)	1		
1	3516	816528A 4	DRIVESHAFT HOUSING (JET 45)	1		
2	16	90350 7	STUD	1		
2	16	90350 1	STUD (60 PONTOON - LONG)	1		
2	16	816866 4	STUD (60 PONTOON - LL)	1		
3A	16	816866 3	STUD (60 PONTOON - LL)	4		
3	10	40003 80	SCREW	4		
4	12	43042	WASHER	4		
5	12	45175	WASHER	1		
6	11	13914	NUT	1		
7	22	85822A 7	SPEEDOMETER PICK-UP ASSEM	1		
8	22	13035	FITTING	1		
9	22	85822	CONNECTOR (STRAIGHT)	1		
10	10	42973	BOLT	2		
11		812892	LOWER MOUNT	2		
12	12	30119	WASHER	2		
13		88238A 2	GROUND WIRE	1		
14	11	43528	NUT	2		
15	10	40011149	SCREW	4		
16		93192	CLAMP	2		
17	11	35521	NUT	4		
18		67077T	COVER (BLACK)	2		
18		67077 6	COVER (GRAY)	2		
18		67077F 2	COVER (TRACKER)	2		
19	10	88417	SCREW	4		
20	23	813745	SPACER	1		
20	23	813745 1	SPACER (60 PONTOON - LL)	1		
21		43585	COUPLING	1		