



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		816728	STARTER HOUSING	1		
2		816765	REST	1		
3		813607	2 SEAL	1		
4	10	821704	75 SCREW	2		
5	23	821702	SPACER	2		
6	23	816086	BUSHING	4		
7	25	815795	GROMMET	8		
8	12	69057	WASHER	8		
9	11	40119	6 NUT	4		
10		816748	1 INTERLOCK CABLE	1		
11	10	821428	1 SCREW	1		
12	12	73288	1 WASHER	1		
13	18	27769	1 COTTER PIN	1		
14	10	812832	1 SCREW	1		
15	11	821027	1 PUSH NUT (DESIGN I)	1		
15A	18	27769	1 COTTER PIN (DESIGN II)	1		
15B	12	35462	1 WASHER (DESIGN II)	1		
-		816728A	9 RECOIL STARTER (S/N 0G23916)	1		
-		816728A10	10 RECOIL STARTER (S/N 0G23916)	1		
16	24	826791	1 SPRING	1		
17		816690	2 INTERLOCK LEVER	1		
18		816712	1 CAM	1		
19		816711	1 RETAINER	1		
20	10	818249	1 SCREW	3		
21		90478	1 FELT PAD (DESIGN I)	1		
21A	13	826229	1 WASHER - SPRING (DESIGN II)	1		
22	24	86857	1 SPRING	1		
23	50	825269	1 STARTER SHEAVE	1		
24	24	86851	2 SPRING	2		
25		86850	2 CAM	2		
26	53	86849	2 RETAINING RING	2		
27	50	12066A	9 STARTER ROPE	1		
28		85174A	1 HANDLE ASSEMBLY	1		
29	24	86852	1 SPRING	1		
30		86853	1 CAM	1		
31	10	826253	1 SCREW	1		
32		42690	1 BUSHING	1		
33	53	818853	1 RETAINING RING	1		