



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	2142	6228A 1	COWL, STARBOARD (MERCURY)	1	1
1	2142	6228A 2	COWL, STARBOARD (DARK GRA		1
1	2142	6228A 3	COWL, STARBOARD (LIGHT GRA		1
2	26	60297	SEAL, FUEL CONNECTOR - COV	1	
3	2141	6227A 1	COWL, PORT (MERCURY)	1	1
3	2141	6227A12	COWL, PORT (DARK GRAY)(MAF	1	1
3	2141	6227A17	COWL, PORT (LIGHT GRAY)(MAF	1	1
4	26	60298	SEAL, CONTROL CABLES - COV	1	
5		89717	BRACKET, COWL SEALING - REA	1	
6		69876 1	SEAL, REAR BRACKET	2	
7		90980	BRACKET, COWL HINGE	2	
8	10	45561	SCREW, HINGE BRACKET (LOWE	2	
8	10	75794	SCREW, HINGE BRACKET (UPPE	2	
9		75805	CAP, HINGE BRACKET SCREW (L	2	
10	13	26992	LOCKWASHER, HINGE BRACKET	4	
11	12	37998	WASHER, HINGE BRACKET SCR	4	
12	12	75806	WASHER, HINGE BRACKET SCR	2	
13		90979	PIN, COWL HINGE	4	
14	10	28782	SCREW, PIN TO COWL (7/8")	4	
15	13	26993	LOCKWASHER, PIN ATTACHING	4	
16		46785A 2	COWL LATCH ASSEMBLY	2	
17		62628	BARREL, COWL LATCH	2	
18	10	31312	SCREW, LATCH ASSEMBLY TO E	2	
19		62627	BAR, ADJUSTMENT - COWL LATI	2	
20		62629	BARREL, COWL LATCH	2	
21	24	62624	SPRING, TENSION - COWL LATC	2	
22	12	30164	WASHER, ADJUSTMENT BAR TC	2	
23	11	45812	NUT, ADJUSTMENT BAR TO BAF	2	
24	2143	7254A 3	FRONT COVER (MERCURY)	1	1
24	2143	7254A 9	FRONT COVER (DARK GRAY)(MA	1	1
24	2143	7254A12	FRONT COVER (LIGHT GRAY)(M	1	1
25		79551	BLANKET, SOUND ABSORBING	1	
26		61158	HOOK, FRONT COVER	1	
27	10	69570	SCREW, HOOK TO FRONT COV	1	
28		47341A 1	STARTER ROPE	1	(FOR MANUAL STARTING ONLY)