



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	865	8362A 4	CYLINDER BLOCK ASSEMBLY (5)	1	
1	865	8362A 4	CYLINDER BLOCK ASSEMBLY (6)	1	
2		66517	RESTRICTOR, CRANKCASE BL	2	
3	27	60286	GASKET, CRANKCASE TO CYLI	2	5
4	16	68201	STUD, CRANKCASE TO DRIVE	2	
5	17	20033	DOWEL PIN, CRANKCASE TO C	2	
6	17	20323	DOWEL PIN, CYLINDER BLOCK	2	
7	16	92345	STUD, CYLINDER BLOCK (4-3/E	2	
8	16	68202	STUD, CYLINDER BLOCK (3") -	1	
8	16	68167	STUD, CYLINDER BLOCK (2-9/1	1	
9		77636	COVER, STARTER MOTOR (BO	1	
10	10	77065	SCREW, STARTER MOTOR CO	2	
11	13	26993	LOCKWASHER, STARTER MOT	4	
12		79735A 1	COVER, STARTER MOTOR (TO	1	
13	10	58414	SCREW, STARTER MOTOR CO	1	
13	10	35385	SCREW, STARTER MOTOR CO	1	
14	10	35385	SCREW, CRANKCASE TO CYLIN	10	
14	10	73657	SCREW, CRANKCASE TO CYLIN	2	
14	10	22039	SCREW, CRANKCASE TO CYLIN	2	
15	12	26020	WASHER, CRANKCASE SCREW	14	
16	11	29250	NUT, CRANKCASE SCREW (BOT	2	
17		79736	INDICATOR, TIMING	1	
18	10	58414	SCRWE, INDICATOR TO STARTE	1	
19	12	56720	WASHER, INDICATOR SCREW	1	
20	1161	6357A 1	END CAP ASSEMBLY, UPPER	1	
21	25	64966	"O" RING, END CAP	1	5
22	26	41953	OIL SEAL, END CAP	1	
23	10	73169	SCREW, UPPER END CAP MOUN	4	
24	15	73644A 1	SHIM, UPPER END CAP (.006-8-1)	AR	4
25	1144	6691A 1	END CAP ASSEMBLY, LOWER	1	
26	25	32546	"O" RING, END CAP	1	5
27	26	41953	OIL SEAL, END CAP	2	
28	10	69034	SCREW, LOWER END CAP MOUN	3	
29	15	20085A 1	SHIM, LOWER END CAP (.002-3-E	AR	4
30	22	29111	CONNECTOR, HOSE TO CYLINDE	1	
31	32	77457 2	HOSE, TELL TALE (15")	1	
32	23	90882	SLEEVE, TELL TALE HOSE	1	
33		69555	NOZZLE, TELL TALE - REAR SUF	1	
34	54	70705	CLAMP, TELL TALE NOZZLE	1	
35	10	48408	SCREW, TELL TALE CLAMP	1	
27		89449A 27	GASKET SET	1	