



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1643	7406A30	GEAR HOUSING ASSY. (SHORT)	1	
-	1643	7406A31	GEAR HOUSING ASSY. (LONG SI)	1	
-	1643	7406A42	GEAR HOUSING ASSEMBLY (LOP)	1	
1	1643	7406A16	GEAR HOUSING ASSEMBLY ME	1	
1	1643	7406A41	GEAR HOUSING ASSEMBLY MA	1	
2	22	85822A	CONNECTOR ASSEMBLY, SP	1	
3	17	85500	DOWEL PIN, GEAR HOUSING	2	
4	16	33778	STUD, WATER PUMP (2-5/8")	3	
5	16	57933	STUD, GEAR HOUSING	2	
6	31	62091	ROLLER BEARING, DRIVE SH	1	
7		72849A	SCREEN, WATER INTAKE - S	1	
8	10	36070	SCREW, WATER INTAKE SCF	1	
9	11	45812	NUT, WATER INTAKE SCREE	1	
10		92815	PLATE, SUPPORT - EXHAUST	1	
11		37721	SEAL, EXHAUST TUBE	1	5,3
12	43	88019	PINION GEAR	1	
13	11	55910	NUT, PINION GEAR TO DRIVE	1	
14	27	77417	GASKET, WATER PUMP	1	5,3,6
15	25	26722	"O" RING, WATER PUMP BASE	1	5,3,6
16	46	77177A	WATER PUMP BASE ASSEMBL	1	3
17	26	79831	OIL SEAL, WATER PUMP BAS	1	3,6
18	26	90562	OIL SEAL, WATER PUMP BAS	1	3,6
19	17	35973	DOWEL PIN, WATER PUMP E	2	3
20	27	32769	GASKET, LOWER - WATER PUI	1	5,3,6
21		54705	PLATE, FACE - WATER PUMP	1	3
22	27	32770	GASKET, UPPER - WATER PUM	1	5,3,6
23	47	89983	IMPELLER, WATER PUMP	1	3
24	28	56662	KEY, IMPELLER DRIVE	1	3
25	46	77822A	WATER PUMP BODY ASSEMBL	1	3
26		48753	INSERT, WATER PUMP BOD	1	3
27	26	38452	SEAL, RUBBER - WATER PUM	1	5,3,6
28	12	38453	WASHER, NYLON - WATER F	1	3,6
29	12	29245	WASHER, WATER PUMP STUC	3	
30	11	20361	NUT, WATER PUMP STUDS	3	
31	25	20273	RING, RUBBER (DRIVE SHAFT)	1	5,3,6
32		78654A	SEAT ASSEMBLY	1	
33		86304	SEAL, SPLINED	1	5
34	10	79953	SCREW, GREASE FILLER	1	
35	22	67892	SCREW, DRAIN (MAGNETIC)	1	
36	12	20260	WASHER, GREASE FILLER AN	2	3,6
37		88181	SLEEVE, LUBRICATION	1	