



EXHAUST PLATE

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		19653A	EXHAUST PLATE ASSEMBLY	1	
-	21	817519A	CHECK VALVE	1	
2	17	23784	DOWEL PIN	4	
3		812893	UPPER MOUNT	1	
4	10	40011153	SCREW	4	
5	10	42973	SCREW	2	
6	12	93416	WASHER	2	
7	12	28421	WASHER	2	
8	11	90099	NUT	2	
9	10	40011158	SCREW	1	
10	27	812866	GASKET	1	2
11	23	48237	BUSHING	1	
12		815639A	SHIFT SHAFT (UPPER)(SHORT)	1	
12		812891A	SHIFT SHAFT (UPPER)(LONG - 5C)	1	
12		815639A	SHIFT SHAFT (UPPER)(LONG - 5E)	1	
12		812891A	SHIFT SHAFT (60 PONTOON - EL)	1	
12		815639A	SHIFT SHAFT (60 SEAPRO/MARZ)	1	
13		812872	SHIFT LINK	1	(USE WITH WAVE WASHER)
14	23	42994	BUSHING	1	(USE WITH WAVE WASHER)
15	13	29720	WAVE WASHER	1	(USE WITH WAVE WASHER)
16	12	24664	WASHER	1	(USE WITH WAVE WASHER)
13		812872A	SHIFT LINK	1	(USE W/O WAVE WASHER)
14	23	48475	BUSHING	1	(USE W/O WAVE WASHER)
17	11	40063	NUT	1	
18	32	43014	WATER TUBE (SHORT)	1	
18	32	43014	WATER TUBE (LONG)	1	
19	25	93221	GROMMET	1	2
20		19655	EXHAUST TUBE	1	
21	10	40011153	SCREW	4	
22		812886	SEAL	1	
23		99019	CLAMP	1	
24		42941	SEAL (UPPER)	1	2
25	10	40011155	SCREW	2	
-	27	812867A97	ENGINE GASKET SET	1	