



## Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
24	91	63209	HEAT LAMP	1		
25	91	877321A	BEARING INSTALLATION TOOL	1		
26	91	804063	TUBING CLAMP	1		
	91	31229A	BEARING REMOVAL & INSTALLA	1		
27		NSS	EXPANDING ROD (P/N-CG-41-1	1		
28		NSS	COLLET (P/N -CG-41-14)	1		
29	11	24156	NUT	1		
30	12	34961	WASHER	1		
31	91	29310	PLATE	1		
32	91	31229	SHAFT	1		
33	91	36571T	MANDREL	1		
34	91	37323	DRIVER ROD	1		
35	91	15755T	MANDREL	1		
36	91	36569T	MANDREL	1		
37	91	27780	BEARING PULLER TOOL	1		
38	91	37241	UNIVERSAL PULLER PLATE	1		
39	91	37312T	DRIVER HEAD	1		
40	91	817011T	DRIVER	1		
41	84	825003A	DDT CABLE - 10FT.	1		
42	91	809871	VACUUMMATE CARB TUNER	1		
43	91	817007T	DRIVER	1		
44	91	43506T	BEARING RETAINING TOOL	1		
45	91	817005	FORWARD GEAR BEARING INST	1		
46	91	817006	WATER PUMP BASE SEAL INST/	1		
47	91	817008A	PINION GEAR LOCATION TOOL	1		
48	91	817009T	FOWARD GEAR BEARING RACE	1		
49	91	12349A2	PINION GEAR LOCATION TOOL	1		
50	91	13945	BEARING INSTALLATION TOOL	1		
51	91	13949	OIL SEAL DRIVER	1		