



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|------------------------------|-----|---------|----------|
| 1 | | 44357Q 2 | FLUSHING ATTACHMENT | 1 | | |
| 2 | | 802889Q 1 | CRANKCASE OIL PUMP | 1 | | |
| 3 | 91 | 802653Q02 | WRENCH, Oil Filter | 1 | | |
| 4 | 91 | 83163M | FLYWHEEL HOLDER | 1 | | |
| 5 | 91 | 83164M | FLYWHEEL PULLER | 1 | | |
| 6 | 91 | 99379 | TIMING LIGHT | 1 | | |
| 7 | 91 | 89045 | ADAPTOR TOOL | 1 | | |
| 8 | 91 | 892647A01 | MULTI-METER KIT, DMT 2004 | 1 | | |
| 9 | 91 | 823686A 2 | DIGITAL DIAGNOSTIC TESTER | 1 | | |
| 10 | 91 | 880118A03 | DDT CARTRIDGE | 1 | | |
| 11 | 91 | 822560A 5 | HARNES ASSEMBLY, DDT Adap | 1 | | |
| 12 | 91 | 883877A 1 | FUEL INJECTOR REMOVAL TOOL | 1 | | |
| 13 | | NSS | NOT SOLD SEPARATE, Lock Ring | 1 | | |
| 14 | 91 | 809495A 1 | VALVE GUIDE REMOVER | 1 | | |
| 15 | 91 | 809496A 1 | VALVE GUIDE INSTALLER BUSH | 1 | | |
| 16 | 91 | 809497A 1 | VALVE GUIDE REAMER | 1 | | |
| 17 | 91 | 809494A 1 | VALVE SPRING COMPRESSOR | 1 | | |
| 18 | | NSS | NOT SOLD SEPARATE, Valve Se | 1 | | |
| 19 | | FT2997 | PISTON RING COMPRESSOR | 1 | | |
| 20 | 92 | 802867Q 1 | ANTI-CORROSION GREASE | 1 | | |
| 21 | 91 | 24697 | EXPANDER TOOL, Piston Ring | 1 | | |
| 22 | 91 | 74951 | SPANNER WRENCH | 1 | | |