



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1334	2031	CARBURETOR ASSEMBLY, COM	1,1,1		
2	1399	110A 1	FLOAT ASSEMBLY	1,1,1		
3	17	20853	PIN, FLOAT LEVER PINION	2,2,2		0
4	1399	102	LEVER, FLOAT (LOWER)	1,1,1		0
5	1399	101	LEVER, FLOAT (UPPER)	1,1,1		0
6	1399	1138	INLET NEEDLE, SEAT AND GAS	1,1,1		0
7	27	25033	GASKET, INLET SEAT	1,1,1		2,0
8	1399	99	GASKET, FLOAT BOWL COVER	1,1,1		2
9	1399	1133	COVER, FLOAT BOWL	1,1,1		
10	10	20854	SCREW, FLOAD BOWL COVER	1,1,1		
11	10	25850	SCREW, FLOAD BOWL COVER	1,1,1		
12	27	34614	GASKET, STRAINER COVER (L	1,1,1		2
13	1399	1754	SCREEN, FILTER	1,1,1		0
14	27	25849	GASKET, STRAINER COVER (S	1,1,1		2
15	1399	1135	COVER, STRAINER	1,1,1		
16	27	25848	GASKET, STRAINER COVER SC	1,1,1		2
17	10	25822	SCREW, STRAINER COVER	1,1,1		0
18	10	20847	SCREW, THROTTLE STOP LEV	1,1,1		0
19	1399	97	LEVER, THROTTLE STOP	1,1,1		
20	1399	1716	SHAFT, THROTTLE	1,1,1		
21	1399	2037	TUBE, IDLE	1,1,1		0
22	27	23180	GASKET, IDLE TUBE	1,1,1		
23	10	23035	SCREW/LOCKWASHER, THRO	1,1,1		0
24	1399	699	SHUTTER, THROTTLE	1,1,1		
25	19	20011	WELCH PLUG, BODY CHANNEL	1,1,1		0
26	24	26890	SPRING, THROTTLE SHAFT RE	1,1,1		0
27	10	28845	SCREW, PLUG-BODY CHANNEL	1,1,1		
28	1399	2036	MAIN NOZZLE	1,1,1		0
29	10	23178	SCREW, PLUG-MAIN NOZZLE	1,1,1		
30	1399	1767	JET, MAIN FUEL (.047)	OPT,OI		
30	1399	1765	JET, MAIN FUEL (.045)-STANDA	1,1,1		0
30	1399	1864	JET, MAIN FUEL (.043)	OPT,OI		
30	1399	1896	JET, MAIN FUEL (.041)	OPT,OI		
31	27	28409	GASKET, MAIN FUEL JET	1,1,1		2
32	27	28406	GASKET, JET CHANNEL PLUG	1,1,1		2
33	10	28405	SCREW, PLUG-MAIN FUEL JET	1,1,1		
34	1399	2038	SCREW, IDLE ADJUSTMENT	1,1,1		0
35	24	27160	SPRING, IDLE ADJUSTMENT S	1,1,1		0
--	1399	1717	GASKET AND PACKING SET	1,1,1		0
--	1399	2039	REPAIR PARTS KIT	1,1,1		
36	27	22022	GASKET, CARBURETOR FLANGE	1,1,1		2