



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	835	1770A 2	CYLINDER BLOCK AND CRANK	1,1,1	SERIAL 01489407-09999999	
1	835	1956A 2	CYLINDER BLOCK AND CRANK	1,1	SERIAL 00000000-01489408	
1	835	2294A 2	CYLINDER BLOCK AND CRANK	1,1,1	SERIAL 00000000-01582403	
2	21	30819A 1	CHECK VALVE ASSEMBLY, CRA	1,1,1,1		
3	16	20789	STUD, CYLINDER BLOCK AND	6,6,6,6		
4	16	21723	STUD, CARBURETOR MOUNTI	2,2,2,2		
5	17	21438	PIN, DOWEL-CRANKCASE TO C	2,2,2,2		
6	22	30139	PLUG, PIPE-CYLINDER BLOCK	1,1,1		
7	10	31294	SCREW, CRANKCASE TO CYLIN	8,8,8,8		
8	10	24624	SCREW, CRANKCASE TO CYLIN	2,2,2,2		
9	11	24652	NUT, CRANKCASE FASTENING S	10,10,1		
10	10	20665	SCREW, MAIN BEARING LOCKIN	1,1,1,1		
11	13	21709	LOCKWASHER, MAIN BEARING L	1,1,1,1		
12	15	30502A 1	SHIM, UPPER BEARING HOUSIN	AR,AR		
13	1127	1775A 1	BEARING HOUSING ASSEMBLY,	1,1,1	SERIAL 01583852-09999999	
14	30	20861	BEARING, BALL-UPPER BEARIN	1,1,1	SERIAL 01583852-09999999	
15	31	28157	BEARING, ROLLER-UPPER BEA	1,1,1	SERIAL 01583852-09999999	
16	26	30943	OIL SEAL, UPPER BEARING HC	1,1,1	SERIAL 01583852-09999999	
13A	1131	2247A 2	BEARING HOUSING ASSEMBLY,	1,1,1	SERIAL 00000000-01610265	
14	30	20861	BEARING, BALL-UPPER BEARIN	1,1,1	SERIAL 00000000-01610265	
15	31	31410	BEARING, ROLLER-UPPER BEA	1,1,1	SERIAL 00000000-01610265	
16	26	31411	OIL SEAL, UPPER BEARING HC	1,1,1	SERIAL 00000000-01610265	
17	25	20826	"O"RING, UPPER BEARING HO	1,1,1,1	SERIAL 00000000-01610265	
18		33899	CLAMP, HOLD DOWN RING	2,2	SERIAL 00000000-01610265	
19	24	27087	SPRING, HOLD DOWN RING CLA	4,4	SERIAL 00000000-01610265	
20	10	20456	SCREW, HOLD DOWN RING CLA	4,4	SERIAL 00000000-01610265	
13A	1131	2405A 1	BEARING HOUSING ASSEMBLY,	1,1	SERIAL 01677523-09999999	
14	30	20861	BEARING, BALL-UPPER BEARIN	1,1	SERIAL 01677523-09999999	
15	31	31410	BEARING, ROLLER-UPPER BEA	1,1	SERIAL 01677523-09999999	
16	26	31411	OIL SEAL, UPPER BEARING HC	1,1	SERIAL 01677523-09999999	
17	25	20826	"O"RING, UPPER BEARING HO	1,1	SERIAL 01677523-09999999	
18	54	34598	CLAMP, HOLD DOWN RING	2,2	SERIAL 01677523-09999999	
19	24	34731	SPRING, HOLD DOWN RING CL	4,4	SERIAL 01677523-09999999	
20	10	36205	SCREW, HOLD DOWN RING CL	4,4	SERIAL 01677523-09999999	
21	10	35662	SCREW, UPPER BRG. HSG. MOL	4,4,4,4	SERIAL 01879786-09999999	
21	10	39002	SCREW, UPPER BRG. HSG. MOL	4		
22	27	22656	GASKET, TRANSFER PORT COVE	1,1,1,1		
23		30654	COVER, TRANSFER PORT	1,1,1,1		
24	10	20665	SCREW, PORT COVER TO CYLIN	3,3,3,3		
25		31014	MOUNT, RUBBER-CYLINDER BL	2,2,2,2		
		26982	LOCKWASHER, RUBBER MOUNT	2		