

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1538	1776A 1	DRIVE SHAFT HOUSING ASSEMBLY	1,1...		
1	1538	1937A 1	DRIVE SHAFT HOUSING ASSEMBLY	1,1...	SERIAL 01552144-09999999	
2	16	30715	STUD, DRIVE SHAFT HOUSING	1,1,1...	SERIAL 01552144-09999999	
1	1538	2243A 1	DRIVE SHAFT HOUSING ASSEMBLY	1,1,1	SERIAL 00000000-01582403	
2	16	34378	STUD, DRIVE SHAFT HOUSING	1,1,1	SERIAL 00000000-01582403	
3	11	21528	NUT, DRIVE SHAFT HOUSING TO DRIVE	1,1,1,1.		
4	11	20509	NUT, GEAR HOUSING TO DRIVE	1,1,1,1.		
5	11	24652	NUT, DRIVE SHAFT HOUSING TO DRIVE	6,6,6,6.		
6	32	30797	TUBE, WATER OUTLET	1,1...		
6	32	31940	TUBE, WATER OUTLET	1,1,1,1		
7	26	30811	SEAL, RUBBER - WATER OUTLET	1,1,1,1.	SERIAL 01734583-09999999	
7A	26	36556	SEAL, RUBBER - WATER OUTLET	1,1	SERIAL 00000000-17734584	
8	12	36554	WASHER, NYLON - OUTLET TUBE	1,1	SERIAL 00000000-17734584	
9	27	30804	GASKET, BOTTOM COWL TO DRIVE	1,1,1,1.		
10	1539	1777	SADDLE	1,1...		
10	1539	1935	SADDLE	1,1,1,1		
11		30646A 1	MOUNT ASSEMBLY, UPPER	2,2,2,2.		
12		30646A 2	MOUNT ASSEMBLY, LOWER	2,2,2,2.		
13	53	26406	RING, RETAINING - UPPER AND LOWER	4,4,4,4.		
14		30648	COVER, UPPER AND LOWER MOUNT	4,4,4,4.		
15	10	30675	SCREW, UPPER AND LOWER MOUNT	4,4,4,4.		

