



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	20696	NUT, FLYWHEEL	1,1		
2	12	27025	WASHER, FLYWHEEL NUT	1,1		
2	12	36245	WASHER, FLYWHEEL NUT	,1	SERIAL 01677714-01734583	
2	12	36282	WASHER, FLYWHEEL NUT	,1	SERIAL 00000000-01734584	
3	25	36284	"D" RING, FLYWHEEL HUB	,1	SERIAL 00000000-01734584	
4	28	20094	KEY, FLYWHEEL DRIVE	2,2		
5	19	29900	PLUG, PLASTIC - FLYWHEEL SCF	3,3		
6	219	2246A 2	FLYWHEEL ASSEMBLY, COMPLE	1,1		
7	23	34367	COLLAR, FLYWHEEL DUST SH	1,1		
8	13	22027	WASHER, WAVE-MAGNETO CAM	1,1		
9	398	2574A 1	STATOR PLATE ASSEMBLY, CON	1,1		
10		35599A 1	SHIELD ASSEMBLY, MAGNETO	,1		
11	10	34695	SCREW, SHIELD TO MAGNET	2,2		
12	13	26996	LOCKWASHER, SHIELD TO M	2,2		
13		33904	RING, HOLD DOWN-STATOR P	1,1		
14	10	35400	SCREW, HOLD DOWN RING TO	4,4		
15	398	2230	CAM, BREAKER	1,1		
16	15	33910	SHIM, STATOR PLATE TO UPPE	1,1		
17		34363A 1	THROTTLE CAM BRACKET ASSE	1,1		
18	54	34449	CLIP, THROTTLE CAM BRACKET	1,1		
19		34374	CAM, THROTTLE	1,1		
20	10	35450	SCREW, THROTTLE CAM TO CAI	4,4		
21	10	34696	SCREW, THROTTLE CONTROL L	1,1		
22	13	29720	WASHER, WAVE-THROTTLE COI	1,1		
23	12	34392	WASHER, THROTTLE CONTROL	2,2		
24	11	28656	NUT, THROTTLE CONTROL LEVI	1,1		