

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	605	378A 2	CONNECTING ROD ASSEMBLY	2,2,2,2		
2	10	21637	SCREW, CONNECTING ROD	4,4,4,4		
3	29	22591	BEARING, NEEDLE-CRANKPIN	46,46,4		
4	11	20565	NUT, CONNECTING ROD SCRE	4,4,4,4		
5	12	30373	WASHER, NEEDLE BEARING R	4,4,4,4		
6	29	22591	BEARING, NEEDLE-PISTON PIN	34,34,3		
7	703	1830A 4	PISTON AND PISTON PIN ASSEM	2,2,2,2		
8	40	22652	LOCK RING, PISTON PIN	4,4,4,4		
9	39	22593	RING, PISTON	6,6,6,6		

