



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		35387	HANDLE, CHROME-TOP COWL	1,1		
2	12	20583	WASHER, CHROME HANDLE STI	1,1		
3	12	29245	WASHER, INSIDE HANDLE TO CI	3,3		
4	13	26992	LOCKWASHER, CHROME HANDL	2,2		
4	12	22937	WASHER, CHROME HANDLE STI	1,1		
5	11	20088	NUT, INSIDE HANDLE TO CHROF	2,2		
5	11	20361	NUT, INSIDE HANDLE TO CHROF	1,1		
6	10	28636	SCREW, INSIDE HANDLE TO CHI	1,1		
7	13	26992	LOCKWASHER, INSISDE HANDLI	1,1		
8		35436	HANDLE, INSIDE-TOP COWL	1,1		
9	10	22956	SCREW, INSIDE HANDLE TO CHI	1,1		
10	12	29245	WASHER, INSIDE HANDLE TO CHI	1,1		
11	11	24652	NUT, INSIDE HANDLE TO CHROF	1,1		
12		35384	KEY, TOP COWL HANDLE	1,1		
13		35407	SCREEN, VENT	1,1		
14	10	30663	SCREW, VENT SCREEN TO TOP	2,2		
15		31024	BRACKET, REAR-TOP COWL MO	1,1		
16	10	38787	SCREW, REAR BRACKET TO TOI	3,3		
17	14	20165	TAB WASHER, SHEAVE SHAFT N	1,1		
18	11	20166	NUT, SHEAVE SHAFT (LEFT HAN)	1,1		
19	2107	2362	COWL, TOP	1,1		
20		35437	BRACKET, PORT-TOP COWL FAC	1,1	SERIAL 00000000-01877455	
20		35438	BRACKET, STARBOARD-TOP CO'	1,1	SERIAL 00000000-01877455	
20		38956	BRACKET, PORT-TOP COWL FAC	,1	SERIAL 01877456-09999999	
20		38959	BRACKET, STARBOARD-TOP CO'	,1	SERIAL 01877456-09999999	
21	10	37655	SCREW, BRACKET TO TOP COW	4,4		
22	11	27164	NUT, BRACKET TO TOP COWL S	4,4		
23	37	35484A	DECAL SET, TOP COWL (NOT AS	1,		
23	37	37746A	DECAL SET, TOP COWL	,1		
24	12	35647	WASHER, STARTER SPRING RE	1,	USED ON EARLY PRODUCTION	
25		20155	RETAINER, STARTER SPRING	1,1		
26	24	29340A	SPRING, STARTER REWIND	1,1		
27	23	28912	BUSHING, SPRING GUIDE	1,1		
28	50	30594A	STARTER SHEAVE ASSEMBLY	1,1		
29	17	22896	PIN, RETAINER-STARTER CAB	1,1		
30	13	36206	WASHER, WAVE-STARTER PAW	3,3		
31		30596	PAWL, STARTER	3,3		
32	23	28919	BUSHING, NYLON-SHEAVE SHAF	1,1		
33	23	28911	SPACER, SHEAVE SHAFT	1,		
33	23	35560	SPACER, SHEAVE SHAFT	1,1		3
34		26179	RETAINER, SHEAVE SHAFT TO	1,1		