



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		39028A 3	ADAPTOR PLATE ASSEMBLY	1,1		
1		47260A 2	ADAPTOR PLATE ASSEMBLY	1,1		0
2	12	36554	WASHER, NYLON - WATER OU	1,1,1		
3	26	36556	SEAL, RUBBER - WATER OUTL	1,1,1		4
4		39044	SEAL, RUBBER - ADAPTOR PL	1,1,1		
5	27	45748	GASKET, POWERHEAD PLATE	1,1,1	SERIAL #2080069-09999999	4
5	27	31557	GASKET, POWERHEAD TO ADAF	1,,	SERIAL 00000000-#2080068	4
5	27	31557	GASKET, POWERHEAD TO ADAF	1,1,1		
6	10	22486	SCREW, ADAPTOR PLATE TO DF	1,1,1		
7	13	26992	LOCKWASHER, ADAPTOR PLATE	1,1,1		
8	27	39050	GASKET, ADAPTOR PLATE TO D	1,1,1		
9	2124	2649	COWL, BOTTOM	1,1,1		
10		39085	ANCHOR, LATCH - BOTTOM COW	1,1,1		
11	10	22485	SCREW, LATCH ANCHOR TO BO	2,2,2		
12	13	26992	LOCKWASHER, LATCH ANCHOR	2,2,2		
13	25	39054	GROMMET, CHOKE SHAFT - BOT	1,1,1		
14		39051A 1	PLATE ASSEMBLY, COVER - BOT	1,1,1		
15		39068	PAD, SOUND - COVER PLATE	1,1,1		
16	10	30009	SCRW, COVER PLATE TO BOTTC	2,2,2		
17		39058	SEAL, SHIFT HANDLE - BOTTOM	1,1,1		
18		39145	MOUNT, RUBBER - BOTTOM CO	1,1,1		
19		39144	MOUNT, RUBBER - BOTTOM COV	1,1,1		
20	10	31208	SCREW, RUBBER MOUNT TO BC	4,4,4		
21	11	46887	NUT, ADAAPTOR PLATE TO RUE	2,2,2		
22		39565	SPOOL, NYLON - TOP COWL LAT	1,1,1		
23	10	20456	SCREW, NYLON SPOOL TO BOT	1,1,1		
24	13	26996	LOCKWASHER NYLON SPOOL SI	1,1,1		
25		39147	ADAPTOR, REAR MOUNT TO BO	1,1,1		
26	10	22486	SCREW, REAR MOUNT ADAPTO	2,2,2		
27	13	26992	LOCKWASHER, REAR MOUNT AI	2,2,2		
28		39146	MOUNT, RUBBER - BOTTOM COV	1,1,1		
29	13	26992	LOCKWASHER, REAR MOUNT	1,1,1		
30	11	20088	NUT, REAR MOUNT TO ADAPTO	1,1,1		
31	11	46887	NUT, ADAPTOR PLATE TO REAF	1,1,1		
32		39087	ROD, COWL LATCH - BOTTOM CI	1,1,1		
33		39099	BRACKET, COWL LATCH ROD	1,1,1		
34	10	22486	SCREW, COWL LATCH BRACKET	1,1,1		
35	13	26992	LOCKWSHER, COWL LATCH BRA	1,1,1		
36		39083	HANDLE, COWL LATCH ROD(POI	1,1,1		
37		39098	HANDLE, COWL LATCH ROD (ST	1,1,1		
38	22	22881	BUSHING, NYLON - COWL LATCH	2,2,2		