



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	832	1411A 5	CYLINDER BLOCK AND CRANK	1,1		
2	17	20032	DOWEL PIN,CYLINDER BLOCK	3,3		
3	23	26348	BUSHING,CRANKCASE-COWL	2,2		
4	16	25385	STUD,CARBURETOR MOUNTIN	6,6		
5	17	20033	DOWEL PIN,CRANKCASE TO S	2,2		
6	16	26133	STUD,CRANKCASE TO DRIVE	2,2		
7	16	26135	STUD,CYLINDER BLOCK TO DF	4,4		
8	16	26134	STUD,CYLINDER BLOCK TO DF	2,2		
9	10	22039	SCREW,CRANKCASE TO CYLIND	2,2		
9	10	27005	SCREW,CRANKCASE TO CYLIND	1,1		
10	10	26132	SCREW,CRANKCASE TO CYLIND	2,2		
11	10	22040	SCREW,CRANKCASE TO CYLIND	18,18		
11	10	21574	SCREW,CRANKCASE TO CYLIND	3,3		
12	11	29250	NUT,CRANKCASE FASTENING SI	26,26		
13		26551	BRACKET,CLAMP EXTENSION	2,2		
14		20089	SCREW,MAIN BEARING LOCKIN	3,3		
15	10	20359	SCREW,CENTER MAIN BEARING	2,2		
16	14	20091	TAB WASHER,BEARING LOCKIN	5,5		
17	1100	1438A 1	END CAP ASSEMBLY,UPPER	1,1		
18	26	29476	OIL SEAL	1,1		
19	25	20081	"O" RING	1,1		
20	30	20080	BEARING,BALL	1,1		
21	15	20082A 1	AP TO CRANKCASE (.002-3-5-10)	AR,AR		
22	10	29198	SCREW,END CAP MOUNTING	4,4		
23	1102	1485A 1	END CAP ASSEMBLY,LOWER	1,1		
24	26	29479	OIL SEAL	1,1		
24	26	29478	OIL SEAL	1,1		
25	25	20081	"O" RING	1,1		
26	30	20080	BEARING,BALL	1,1		
--	21	28481A 1	,CHECK VALVE ASSY,END CAP	1,1		
27	15	20085A 1	SHIM,END CAP TO CRANKCASE	AR,AR		
28	10	29198	SCREW,END CAP MOUNTING	3,3		
30	27	26076	GASKET,CYLINDER BLOCK TO M	1,1		
29		30065	PLATE,EXHAUST MANIFOLD	1,1		
30	27	26076	GASKET,MANIFOLD PLATE TO C	1,1		
31		28290	COVER,EXHAUST MANIFOLD	1,1		
32	10	28668	SCREW,MANIFOLD COVER MOU	21,21		
33	54	26519	CLAMP,SPARK PLUG LEADS TO	3,3		
34	397	416A 3	GROUND STRAP ASSEMBLY,CYL	1,1		
35	27	26072	GASKET,CYLINDER BLOCK COVE	1,1		
36	1010	1267A 1	CYLINDER BLOCK COVER ASSEM	1,1		