



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	177	1657A 2	TOP COWL ASSEMBLY	1,1		
2	16	20500	STUD, REAR - TOP COWL TO C	2,2		
3	16	20353	STUD, FRONT - TOP COWL TO	2,2		
4	25	20116	GROMMET, CHOKE KNOB	1,1		
5		28967	SCREEN, VENT - TOP COWL	1,1		
6	10	29221	SCREW, VENT SCREEN TO TO	4,4		
7	37	29834	DECAL SET, TOP COWL	1,1		
8	23	20326	SPACER, TOP COWL STUD	2,2		
9	12	20028	WASHER, TOP COWL STUD (1/1	2,2		
10	12	20346	WASHER, TOP COWL STUD (3/4	4,4		
--	12	20583	WASHER, TOP COWL STUD (1/3	AR,AR		
11	11	20361	NUT, TOP COWL FASTENING	4,4		
12		20155	RETAINER, STARTER SPRING	1,1		
13	24	23714	SPRING, STARTER REWIND	1,1		
14	23	20159	BUSHING, SPRING GUIDE	1,1		
15	50	28895	SHEAVE ASSEMBLY	1,1		
16		20162	PAWL, STARTER	3,3		
17	13	29402	WASHER, WAVE - STARTER PAW	3,3		
18	23	20158	SPACER, SHEAVE SHAFT	1,1		
19		26179	RETAINER, WAVE WASHER	1,1		
20	12	26180	WASHER, WAVE WASHER RETA	1,1		
21	13	20160	WASHER, WAVE - RETAINER TE	1,1		
22		20164	PLATE, RETAINER - STARTER P	1,1		
23		20157	SHAFT, SHEAVE	1,1		
24	50	22791A 1	STARTER CABLE ASSEMBLY	1,1		
25		28747	HANDLE, STARTER CABLE	1,1		
26		28748	RETAINER, STARTER CABLE AN	1,1		
27	14	20165	TAB WASHER, SHEAVE SHAFT N	1,1		
28	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1,1		
29		29274	HANDLE, CHROME - TOP COWL	1,1		
30		29276	HANDLE, INSIDE - TOP COWL	1,1		
31		29413	BUTTON, BUMPER - TOP COWL	1,1		
32	12	20346	WASHER, LOWER HANDLE STU	1,1		
33	12	29245	WASHER, CENTER HANDLE STL	1,1		
34	11	21825	NUT, INSIDE HANDLE TO CHRO	2,2		
35	10	22421	SCREW, FRONT _ HANDLE TO T	1,1		
36	11	20361	NUT, FRONT - HANDLE FASTENI	1,1		
37	10	29199	SCREW, CENTER - HANDLE TO	1,1		
38	23	29561	BUSHING, REAR HANDLE STUD	1,1		
39	12	29245	WASHER, REAR HANDLE STUD	1,1		
40	11	21825	NUT, REAR HANDLE STUD	1,1		