



**Quicksilver Lubrication/Sealant
 Application Points**

 Loctite 271 (Obtain Locally)

EXHAUST PLATE

Parts List									
Ref	Class	Part	Description	Qty	Comment	Footnote			
1		42954A	EXHAUST PLATE ASSEMBLY	1					
2	17	23784	DOWEL PIN	5					
3	10	40011151	SCREW (M8 X 35)	2					
3	10	40011158	SCREW (M8 X 70)	1					
4		44344	MOUNT	1	(NON OIL INJECTION)(LL)				
4		42949	MOUNT	1	(OIL INJECTION) (JET 65)				
5	10	40107 50	SCREW (M8 X 50)	4					
6	10	42974	SCREW (M12 X 175)	2					
7	12	93416	WASHER	2					
8	12	28421	WASHER	2					
9	11	90099	NUT	2					
10	27	43008	GASKET	1		4			
11		42966	EXHAUST TUBE	1					
11		42966A	EXHAUST TUBE	1	(BELGIUM)(INCLUDES RESTRIC				
12	10	40011151	SCREW (M8 X 35)	6					
13		42962	SEAL-EXHAUST TUBE	1					
14	25	89417	GROMMET	1					
15	32	824660	WATER TUBE (13-1/4 IN.)	1					
15	32	824660	WATER TUBE (15-3/4 IN.)	1					
15	32	824660	WATER TUBE (18-1/4 IN.)	1					
16		824661	CLAMP	1					
17		814080	SEAL (UPPER)	1					
18	10	40107 50	SCREW (M8 X 50)	2					
19		42953A	BRACKET ASSEMBLY (LOWER)	1	(BLACK)				
19		42953A	BRACKET ASSEMBLY (LOWER)	1	(GRAY)				
19		42953A	BRACKET ASSEMBLY (LOWER)	1	(TRACKER-GRAPHITE GRAY)				
20		43405	SEAL	1					
21	25	12602	GROMMET	1	(POWER TRIM - S/N-0G360002 &				
21	25	19564	GROMMET	1	(NON POWER TRIM/MANUAL T				
22	25	19565	GROMMET	1	(POWER TRIM - S/N-0G360003 &				
23	10	817427 50	SCREW (M8 X 50)	3					
24	23	48237	BUSHING	1					
25		79932A	SHIFT SHAFT ASSEMBLY	1	(UPPER - ELECTRIC) (S/N-USA-C				
25		79932A19	SHIFT SHAFT ASSEMBLY	1	(UPPER - ELECTRIC) (S/N-0G590	3			
25		79932A13	SHIFT SHAFT ASSEMBLY	1	(UPPER - MANUAL)				
26		42912A	SHIFT LINK	1	(S/N-USA-0G589999/BEL-99730				
26		42912A	SHIFT LINK	1	(S/N-USA-0G590000/BEL-99731	3			
27	23	48475	BUSHING	2					
28	11	826833	NUT	1					
29	23	813745	SPACER	1	(LONG)	1			
29	23	11389	SPACER	1	(X-LONG)(LL)				