



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		85174A	HANDLE ASSEMBLY	1		
2		822072	REST	1		
3		823241	SEAL	1		
4	10	821300 50	SCREW (M6 X 50)	2		
5	12	69057	WASHER	2		
6	23	821702	SPACER	2		
7	23	816086	BUSHING	4		
8	25	815795	GROMMET	8		
9	11	40026	NUT	4	(S/N-0G699128 & BELOW)	
9	11	826833	NUT	6	(S/N-0G699129 & UP)	
10	12	69057	WASHER	8	(S/N-0G699128 & BELOW)	
10	12	69057	WASHER	6	S/N-0G699129 & UP	
11		855596	BRACKET	1	S/N-0G699129 & UP	3
12		855597	BRACKET	1	S/N-0G699129 & UP	3
13	10	40011129	SCREW	2	S/N-0G699129 & UP	
14	12	35462	WASHER	1	S/N-0G699129 & UP	
15		11704A	PULLEY KIT	2	S/N-0G699129 & UP	3
16		NSS	SPACER	2	S/N-0G699129 & UP	10
17	12	67983	WASHER	1	S/N-0G699129 & UP	
18		816748	INTERLOCK CABLE	1		
19	10	821428	SCREW (10-16 X 5/8)	1		
20	12	73288	WASHER	1		
21	18	26811	COTTER PIN	1		1
22	10	812832	SCREW	1		
23	11	821027	PUSH NUT	1	(DESIGN I)	
24	12	35462	WASHER	1	DESIGN II	
25	18	26811	COTTER PIN	1	DESIGN II	1
		816728A14	STARTER HOUSING	1		1
26	24	826791	SPRING	1		
27		816690	INTERLOCK LEVER	1	(S/N-0G242650 & BELOW)	
27		816690	INTERLOCK LEVER	1	(S/N-0G242651 & UP)	
28		816712	CAM	1		
29		816711	RETAINER	1		
30	10	818249	SCREW (10-16 X 1)	3		
31		90478	FELT PAD	1	(DESIGN I)	
32	13	826229	WASHER	1	(DESIGN II)	
33	24	86857	SPRING	1		
34	50	825269A	STARTER SHEAVE	1		
35	24	86851	SPRING	2		
36		86850	CAM	2		
37		86849	RETAINING RING	2		